



The versatile Cuisinart® Sandwich Grill does more than just lunch; press sandwiches, grill omelets, and even crisp French toast in one product! Perfect for dorm rooms and cozy kitchens, the Sandwich Grill can make two items at once, with a lock-down lid guaranteeing both sides cook evenly while the nonstick plates seal in your favorite ingredients. Sizzling cheese sandwiches and fluffy omelets come out perfectly every time with dual indicator lights letting you know when the grill is ready to cook and your meal is ready to eat. The nonstick plates wipe clean after use and the lid lock and cord wrap make storage easy.



- Grills 2 sandwiches, omelets, or servings of French toast
- Lock-down lid positions plates to evenly grill both sides
- Ready to cook and Ready to eat indicator lights
- Raised ridges in cooking plates seal edges of bread or omelets to keep ingredients inside
- Nonstick baking plates wipe clean in seconds
- Deep pockets
- Cord storage
- Limited 3-year warranty
- BPA Free