

USE AND MAINTENANCE

Use on level surfaces only

Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly


Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

Chesterfield Sofa


PART LIST




1 - Sofa Assembly x1




2 - Sofa Arm (Seated) Left




3 - Sofa Arm (Seated) Right



4 - Sofa Back



5 - Sofa x1



6 - Sofa Seat x3




7 - Sofa Leg x4




8 - Sofa Back Cushion x2


Assembly Instructions




Select 4 Sofa Backx1, 2 Sofa Arm (Seated) Left and 3 Sofa Arm (Seated) Right. Insert 2 and 3 into hole in Sofa Back to hand tighten.




Select 5 Sofa Front Panelx1, Insert 5 into the 2 and 3.




Put the 1 Sofa Assembly on the 5.



Put the 6 Sofa Seatx3 on the 1 Sofa Assembly to make sofa comfortable.



Put the 8 Sofa Back Cushionx2 on the sofa, and insert 7 legx4 into the sofa.



Congratulations! Setup of your new Chesterfield Sofa is Complete!