# ASSEMBLY INSTRUCTIONS MODEL: TABLE

### Please read instructions carefully

Remove all wrapping materials, staples and packing straps from the carron. Refer to Parts List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from being scratched. CAUTIONS: 1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.


- 2) DO NOT OVER-TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.
- 3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.

## PARTS LIST (FOR 1 NOS. OF TABLE)


NO.	COMPONENT	QTY.
15-1	TABLE TOP	
P2	PEDESTAL LEG	1
Р3	LEG PRONG	4
P4	MOUNTING PLATE	1


### HARDWARE LIST (FOR 1 NOS. OF TABLE)


NO.	DESCRIPTION	QTY.
Hi	wrench (	1
H2	HEX NUT	8
Н3	SPRING WASHER M8	8
114	FLAT WASHER M8	8
H5	JCBC BOLT M6 x 35mm 💮 📨	4
116	SPRING WASHER M6	4
H7	SCREW M4 X 32mm (December 2)	8
814	ALLEN KEY	1











## CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children and animals, dispose off plastic bags immediately.

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

FITTINGS - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.