Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.

IMPORTANT: PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

"DO NOT OVERTIGHT ANY HARDWARE"

WARNING : SMALL PARTS AND HARDWARE NOT FOR CHILDREN UNDER 3 YEARS. ADULT ASSEMBLY REQUIRED.			
TABLE OF CONTENTS			
HARDWARES LIST	PAGE 2		
PARTS LIST	PAGE 3		
PARTS' LOCATION	PAGE 4		
ASSEMBLY STEPS	PAGE 5		
ASSEMBLY COMPLETED	PAGE 6		
ASSEMBLY TOOLS REQUIRED			
1. Screwdriver (not provide)	2. Hammer (not provide)		

Skip the power drill this time.



DINING CHAIR ASSEMBLY INSTRUCTION HARDWARES LIST QTY ITEM **DESCRIPTION DRAWING** 4 PCS Α JCBC SCREW M6 x 35MM (\emptyset) В 8 PCS JCBC SCREW M6 x 60MM С 8 PCS JCBC SCREW M6 x 80MM D 20 PCS SPRING WASHER M6 x 12mm Ε 20 PCS FLAT WASHER M6 x 19mm

There are total THREE (3) packs of hardware packs. Each hardware pack includes the hardware for TWO (2) chairs.


F


M4 ALLEN KEY (100MM)


1 PC

DINING CHAIR ASSEMBLY INSTRUCTION			
PARTS LIST			
BOX 1			
ITEM	DESCRIPTION	DRAWING	QTY
1	BACKREST		6 PCS
BOX 2			
2	CUSHION SEAT		6 PCS
3	FRONT LEG		12 PCS


PARTS'LOCATION







STEP 3



ASSEMBLY COMPLETED