

ASSEMBLY INSTRUCTION FOR ITEM C251THB-WD

We believe you will absolutely love your new furniture. Please immediately examine this product carefully.

•Description of the problem and/or the Part Number needed

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 business days and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here.








This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.
2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.
3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.



We appreciate your business!

ASSEMBLY INSTRUCTION

HARDWARES LIST


ITEM	DESCRIPTION	DRAWING	QTY
A	JCBC SCREW M6 x 50 MM		4 PCS
B	JCBC SCREW M6 x 35 MM		8 PCS
C	HEX NUT M6 x 5 MM		4 PCS
D	M4 ALLEN KEY		1 PC
E	M6 x 19 MM FLAT WASHER		16 PCS
F	M6 x 12 MM SPRING WASHER		12 PCS
G	CSK SCREW M4 x 32 MM		8 PCS

PARTS LIST

ITEM	DESCRIPTION	DRAWING	QTY
1	HEADBOARD LEG		2 PCS
2	HEADBOARD PANEL		4 PCS


ASSEMBLY TOOLS REQUIRED

1. SCREWDRIVER (NOT PROVIDE)




ASSEMBLY INSTRUCTION

PARTS LOCATION




ASSEMBLY INSTRUCTION

STEP 1



STEP 2



ASSEMBLY
COMPLETE

