Iridescent Lighted Snowman



Illustrated assembly guide

MODEL JL-2032

Finished dimensions
Heights: 36.2 in

Keep the lights off and remove the batteries while assembling the frame. Install batteries only after the frame is secure.

Before you begin

Arrange the components on a clean surface. Snowman body, two arms, hat, attached LED lights and battery pack. Requires 3 AA batteries (not included).




Keep these instructions for reference. Do not pull on the light wires when attaching the decorative parts.

Assembly sequence

Follow the numbered steps. Check each frame and cord connection before applying power.

1 Attach the arms




Fit each arm into the matching connection on the snowman body, as shown. Keep the light wires clear of the joints.

2 Fit the hat




Place the hat onto the matching fittings at the top of the head. Check that the arms and hat are securely seated.

3 Install 3 AA batteries



Open the battery cover. Insert three AA batteries following the + and - markings inside the holder. Close the cover securely.

4 Check the assembly



Stand the snowman upright and check that all frame connections are secure before using the lights.

Assembly sequence

Follow the numbered steps. Check each frame and cord connection before applying power.

5 First press: daily timer



Press the battery-pack button once. Lights stay on for 6 hours, then off for 18 hours. This cycle repeats automatically.

6 Second press: always on



Press the same button again to switch to continuous light. The lights remain on until you change the setting.

7 Third press: off



Press the button a third time to turn the lights off.

Warranty?
Troubleshooting?

Scan the QR code for instructions, support, & registration.

XProductSupport.com/product/JL-2032

Instructions, support & warranty

Scan the mini card or click below to:

Watch the instructional video
Create a support ticket
Register your item for warranty

XProductSupport.com/product/JL-2032