

























Kitchen Cart
ASSEMBLY INSTRUCTIONS






Phillips
Screwdriver
(Not provided)




| | | | | |
|--|---|---|--|---|
| <p>a</p>  <p>5×45mm ×16PCS</p> | <p>b</p>  <p>3×25mm ×8PCS</p> | <p>c</p>  <p>×4PCS</p> | <p>d</p>  <p>×1PC</p> | <p>e</p>  <p>×1PC</p> |
| <p>f</p>  <p>×1PC</p> | <p>g</p>  <p>×2PCS</p> | <p>h</p>  <p>×2PCS</p> | <p>i</p>  <p>4×16mm ×2PCS</p> | <p>j</p>  <p>3×12mm ×1PCS</p> |

| | | | |
|---|--|---|--|
| <p>A</p>  <p>×1PC</p> | <p>B</p>  <p>×1PC</p> | <p>C</p>  <p>×1PC</p> | |
| <p>D</p>  <p>×1PC</p> | <p>E</p>  <p>×1PC</p> | <p>F</p>  <p>×2PCS</p> | |
| <p>G</p>  <p>×2PCS</p> | <p>H</p>  <p>×1PC</p> | <p>I</p>  <p>×1PC</p> | |
| <p>J</p>  <p>×1PC</p> | <p>K</p>  <p>×1PC</p> | <p>L</p>  <p>×1PC</p> | <p>M</p>  <p>×1PC</p> |





1  e×1  j×1



A





2





3




4




5



6

 a×4



7

Please peel off the protective film from the stainless steel top after the unit is fully assembled.

