



ASSEMBLY INSTRUCTIONS











Notice:









1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly.Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.

		
Recommended installers:2	**Put a carpet on the floor before unpacking**	**Estimate installation time: 30minutes**

ASSEMBLY INSTRUCTIONS






PART LIST







Item no.	Reference Image	Qty
A		X1
B		X1
C		X1
D		X1
E		X1
F		X1
G		X1
H		X1

Item no.	Reference Image	Qty
I		X1
J		X1
K		X1
L		X1
M		X1
N		X1
O		X1
P		X1

ASSEMBLY INSTRUCTIONS












PART LIST

Item no.	Reference Image	Qty
Q		X1
R		X1
S		X1
T		X1
U		X2


Item no.	Reference Image	Qty
V		X1
W		X1
X		X1
Y		X1
Z		X1
ZZ		X4

ASSEMBLY INSTRUCTIONS

HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	 Ø8*30mm	X15+1	10	 Ø3*16mm	X2
2		X29+2	11		X4
3		X29+2	12		X5
4	 Ø3.5*50mm	X16+1	13		X2
5	 Ø3.5*30mm	X18+1	14	 Ø5*3/4"	X9
6		X4	15	 Ø1/4"*2"	X4
7		X2	16		X4
8	 Ø3*14mm	X36+3	17	 Ø1/4"*1.0T*D12mm	X4
9		X1	18		X1


ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS


1






ASSEMBLY INSTRUCTIONS

2





F 1PC | 4 8PCS | 9 1PCS | 10 2PCS | 1 5PCS | 2 6PCS



ASSEMBLY INSTRUCTIONS


3






ASSEMBLY INSTRUCTIONS


4






ASSEMBLY INSTRUCTIONS


5






ASSEMBLY INSTRUCTIONS


6






ASSEMBLY INSTRUCTIONS

7




③ 6PCS




Ø3.5*30mm

⑤ 2PCS





① 4PCS




ASSEMBLY INSTRUCTIONS

8









ASSEMBLY INSTRUCTIONS

9





ASSEMBLY INSTRUCTIONS

10





Ø3*14mm

⑧ 24PCS




⑪ 4PCS






ASSEMBLY INSTRUCTIONS


11



1



2



3

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm

Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS


12

Common Door Panel Issues:





Door panel is not straight

Adjust the door hinges




Finished







The gap between door panels is too large

Adjust the door hinges




Finished







The door panels are not coplanar

Adjust the door hinges



Finished







The two door panels are not at the same height

ASSEMBLY INSTRUCTIONS


13







ASSEMBLY INSTRUCTIONS

14









ASSEMBLY INSTRUCTIONS


15






ASSEMBLY INSTRUCTIONS

16




Ⓥ 1PC Ⓦ 1PC Ⓧ 1PC Ⓤ 1PC Ⓨ 1PC ⑤ 8PCS ⑫ 2PCS ⑭ 2PCS



ASSEMBLY INSTRUCTIONS

17



ASSEMBLY INSTRUCTIONS

18

