# ASSEMBLY INSTRUCTIONS
# End Table



**Notice**:

1.Follow the installation instructions. Please confirm all accessories are preset before installation.

2. Do not fully tighten the screws during initial assembly.Fully tighten screws only once all pieces which are correctly assembled.

3. If you encounter any problems during installation, refer to two solutions: Follow the installation video tutorial on the Amazon product page or contact our customer service.

| Item no. | Reference Image | Qty |
|---|---|---|
| ① |  | X1 |
| ② |  | X1 |
| ③ |  | X1 |
| ④ |  | X1 |
| ⑤ |  | X1 |
| ⑥ |  | X1 |
| ⑦ |  | X1 |

| Item no. | Reference Image | Qty |
|---|---|---|
| ⑧ |  | X1 |
| ⑨ |  | X1 |
| ⑩ |  | X1 |
| ⑪ |  | X1 |
| ⑫ |  | X1 |
| ⑬ |  | X2 |
| ⑭ |  | X2 |
| ⑮ |  | X2 |
| ⑯ | | X2 |
| ⑰ | | X2 |
| ⑱ |  | X2 |

**Notice:**

1.Follow the installation instructions. Please confirm all accessories are preset before installation.

2. Do not fully tighten the screws during initial assembly.Fully tighten screws only once all pieces which are correctly assembled.

3. If you encounter any problems during installation, refer to two solutions: Follow the installation video tutorial on the Amazon product page or contact our customer service.

| Item no. | Reference Image | Qty |
|---|---|---|
| A |  | X38 |
| B |  | X38 |
| C | Ø8*30mm | X29 |
| D | 4*35mm | X8 |
| E | | X2 |
| F | 4*12mm | X2 |
| G | Ø3*12mm | X25 |
| H | 4*40mm | X5 |

| Item no. | Reference Image | Qty |
|---|---|---|
| I |  | X1 |
| J | | X4 |
| K | Ø3*17mm | X4 |
| L | Ø3*10mm | X4 |
| CL |  | X2 |
| CR |  | X2 |
| DL |  | X2 |
| DR |  | X2 |

# Explosion Diagram



# STEP 1




| | |
|---|---|
| | **A** x 4pcs |
| | **B** x 4pcs |
| | **C** x 4pcs |




# STEP 2




| | |
|---|---|
| | **A** x 4pcs |
| | **B** x 4pcs |
| | **C** x 4pcs |



## STEP 3




| | |
|---|---|
| | **G** x 12pcs |
|  | **CL** x 2pcs |
|  | **CR** x 2pcs |

## STEP 4







| | |
|---|---|
| | **A** x 4pcs |
| | **B** x 4pcs |
| | **C** x 4pcs |

## STEP 5










| | |
|---|---|
| | **A** x 9pcs |
| | **B** x 9pcs |
| | **C** x 8pcs |
| | **H** x 1pcs |

## STEP 6




| | |
|---|---|
| | **C** x 4pcs |
|  | **H** x 4pcs |

## STEP 7




| | |
|---|---|
| | **A** x 4pcs |

## STEP 8







| | |
|---|---|
| | **B** x 4pcs |
| | **C** x 4pcs |

## STEP 9




**A** x 4pcs

## STEP 10







**B** x 4pcs

## STEP 11




 I x 1set

## STEP 12

**NOTE**:
Rotate the screws counterclockwise to remove it .



## STEP 13




| | |
|---|---|
| | **L** x 4pcs |

## STEP 14

**NOTE**:
Clockwise rotation screws to secure, then close the lid.



## STEP 15




x2

| | |
|---|---|
| | **D** x 8pcs |

## STEP 16










x2

| | |
|---|---|
| | **A** x 8pcs |
| | **B** x 8pcs |

## STEP 17

x2




| | |
|---|---|
| | **G** x 12pcs |
| | **DL** x 2pcs |
| | **DR** x 2pcs |

## STEP 18




x2

| | |
|---|---|
| | **E** x 2pcs |
| | **F** x 2pcs |

## STEP 19






| | |
|---|---|
| | **J** x 4pcs |
|  | **K** x 4pcs |

## STEP 20







**NOTE**:
If the drawer does not go in smoothly, pleas make sure you tighten the screws to the bottom.

# WARRANTY CARD

## Your warranty includes

- **30 Days Money Back Guaranty**
  Within the first 30 days of your purchase, you are allowed to return your product for a full refund.
- **30 Days to 3 Months(6 Months)**
  We will replace the defective unit due to manufacturer fault with a new one. (You will receive extra 3 Months warranty if you register on our website.)
- **3 Months to 24 Months**
  Within 24 Months, we will provide timely and effective online after-sales service after your purchase.