















ASSEMBLY INSTRUCTIONS

- Notice:
- 1.Follow the installation instructions. Please confirm all accessories are preset before installation.
 - 2.Do not fully tighten the screws during initial assembly.Fully tighten screws only once all pieces which are correctly assembled.
 - 3.If you encounter any problems during installation, refer to two solutions: Follow the installation video tutorial on the product page or contact our customer service.


Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
A	 Ø8×16	×10	E	 Ø12	×4
B	 Ø8	×10	F	 Ø12	×4
C	 Ø8	×18	-		×1
D	 Ø8×12	×8			


Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
1		×1	3		×1
2		×4	4		×2
			5		×4
			6		×1


Explosion diagram




1



Ⓐ 8pcs




Ⓑ 8pcs


Ⓒ 8pcs


2


Ⓓ 8pcs



Ⓒ 8pcs




3



Ⓔ4pcs




Ⓕ4pcs




5


4




Ⓐ2pcs



Ⓑ2pcs




Ⓒ2pcs




6

5

Pull out one side
of the ring fastener.





4



6

Pass the buckle
through the hole.



Installation Completed