

ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Allen Wrench



2 - People

ASSEMBLY RATING



EASY ——————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DINING TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.

PARTS

1 1pc



TABLE TOP

2 2pcs




TABLE LEG - LEFT

3 2pcs





TABLE LEG - RIGHT


HARDWARE

A 16pcs




JCBB BOLT
M8 x 25MM

B 16pcs



LOCK WASHER
M8

C 16pcs



FLAT WASHER
M8

D 1pc




ALLEN KEY
M5

E 4pcs



CSK SCREW
M4 x 32MM

F 4pcs





METAL PLATE

ASSEMBLY INSTRUCTIONS

1

Part (2) x 2pcs
Part (3) x 2pcs
Hardware (A) x 8pcs
Hardware (B) x 8pcs
Hardware (C) x 8pcs
Hardware (D) x 1pc
Hardware (F) x 4pcs








With allen key (#D) attach metal plate (#F) to the left/right table leg (#2) and (#3) by using jcbb bolt (#A) with lock washer (#B) and flat washer (#C).

2


Part (1) x 1pc
Part (2) x 2pcs
Hardware (A) x 4pcs
Hardware (B) x 4pcs
Hardware (C) x 4pcs
Hardware (D) x 1pc







DO NOT FULLY TIGHTEN ALL BOLTS ON THIS STEP




Align the left table leg (#2) to the table top (#1) according to the hole stated with L sticker. With allen key (#D) secure using jcbb bolt (#A) with lock washer (#B) and flat washer (#C).


ASSEMBLY INSTRUCTIONS

3

Part (3) x 2pcs
Hardware (A) x 4pcs
Hardware (B) x 4pcs
Hardware (C) x 4pcs
Hardware (D) x 1pc

Align the right table leg (#3) to the left table leg (#2) and table top (#1) and with allen key (#D) secure using jcbb bolt (#A) with lock washer (#B) and flat washer (#C).







FULLY TIGHTEN ALL BOLTS ON THIS STEP

4

Hardware (E) x 4pcs


Fix the left table leg (#2) and right table leg (#3) by using csk screw (#E).





ASSEMBLY INSTRUCTIONS

5



ASSEMBLY COMPLETED


Please ensure the furniture rests on an even and flat surface. if the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!
Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!
To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not Included)




(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY ———— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


DINING ARM CHAIR



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.


PARTS

1 1pc




BACK REST

2 1pc




LEG - LEFT

3 1pc



LEG - RIGHT

4 1pc



CUSHION SEAT

5 1pc



SIDE WOOD - FRONT

6 1pc



SIDE WOOD - BACK


HARDWARE

A 8pcs



JCBC BOLT
M6 x 70MM

B 8pcs



LOCK WASHER
M6

C 8pcs



FLAT WASHER
M6

D 1pc



ALLEN KEY
M4

E 4pcs




CSK SCREW
M4 x 32MM


ASSEMBLY INSTRUCTIONS

1

Part (3) x 1pc
Part (5) x 1pc
Part (6) x 1pc
Hardware (A) x 2pcs
Hardware (B) x 2pcs
Hardware (C) x 2pcs
Hardware (D) x 1pc




Align the front/back side wood (#5,#6) to the right leg (#3) and with allen key (#D) secure by using jcbc bolt (#A) with lock washer (#B) and flat washer (#C).



2

Part (2) x 1pc
Hardware (A) x 2pcs
Hardware (B) x 2pcs
Hardware (C) x 2pcs
Hardware (D) x 1pc


Align the left leg (#2) to the front/back side wood (#5,#6) with allen key (#D) secure by using jcbc bolt (#A) with lock washer (#B) and flat washer (#C).



ASSEMBLY INSTRUCTIONS

3


Part (1) x 1pc



Align the back rest (#1) position to the leg before tightening.

4

Hardware (A) x 4pcs
Hardware (B) x 4pcs
Hardware (C) x 4pcs
Hardware (D) x 1pc




Align the back rest (#1) to the left and right leg (#2)(#3) with allen key (#D) secure by using jcbc bolt (#A) with lock washer (#B) and flat washer (#C).


ASSEMBLY INSTRUCTIONS

5

Part (4) x 1pc


Hardware (E) x 4pcs





Flip chair over and align the cushion seat (#4) to the frame. Secure by using screw (#E).

6



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screw are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.