






ASSEMBLY AND INSTALLATION INSTRUCTIONS

Lightscares Wall Light

WARNING: Turn off the main power at circuit breaker before installing fixture.
AVERTISSEMENT: Coupez la source d'alimentation principale au panneau central de disjoncteurs avant d'installer le luminaire.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. Read and save these instructions.

Hardware Package (included):



Installation Steps

Turn off the power at fuse or circuit box

1. Remove the end cap (D) from mounting strap unit (A).
2. Attach the mounting strap unit (A) to the outlet box by using two mounting screws (B).
Adjust the length of the preinstalled threaded pipe if necessary.

3. Attach the glass panel inside the silhouette panel carefully, then secure the the glass panel with clips-a (See Fig.1).
4. Insert the silhouette unit to the fixture and ensure it is centered within the fixture, then secure it with the clips-b (See Fig.2).
5. Pull out the source wires from the outlet box. Make wire connections using wire connectors (C) as follows:
 - Connect the hot wire (black insulation) from the fixture to the black wire from the power source.
 - Connect the neutral wire (white insulation) from the fixture to the white wire from the power source.
 - Attach the fixture ground wire (bare wire) to the mounting strap unit (A) with the green ground screw, then depending on local code, connect it to the house ground wire with the wire connector (C).
 Carefully put all of the wires back into the outlet box.
6. Attach the backplate of the fixture to the mounting strap unit (A) by inserting the threaded pipe, then secure it with the end cap (D).


Note: With silicone caulk compound, caulk completely around where the backplate meets with the wall surface to prevent water from seeping into the outlet box.
7. Install 1 x 60W max. medium base bulb (not included).

See relamping label at socket area or packaging for maximum wattage allowed.

Turn on the power at fuse or circuit box.


The following parts are available for reorder if damaged or missing.

Spare Parts List:



Assembly Kit
7291MM (1 SET)
for Matte Black Fixture
7292MM (1 SET) for
Warm Bronze Fixture

Glass Panel
10619WG for Matte Black Fixture
10620AFG for Warm Bronze Fixture



A: 11"

B: 8-1/4"

C: 5-1/4"

1 Year Warranty

Vaxcel warrants all of our products against defects in workmanship and finishes for one year following the date of shipment.

Exclusions: This warranty does not include the failure of products from extreme acts of nature; environmental conditions not suited for the products intended use; operation in temperatures outside of the range specified in the instruction manual; usage with improper power supply, power surges or dips. For coastal locations, some corrosion is considered normal for the environment.

Vaxcel reserves the right to repair, replace or issue a credit for any properly installed product, provided it is returned per RMA instruction. This warranty is limited to the cost of the product only and does not extend to transportation, installation or replacement costs.

How can warranty service be obtained?

info@vaxcel.com
1-800-482-9235