



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

SOFA TABLE

REVISION 0 : 09/12/2017
REVISION 1 : 11/03/2022

PAGE 1 OF 4

ITEM: 720229

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 50 MINUTES

PARTS IDENTIFICATION

A


TOP GLASS



1PC

B

SHELF GLASS



2PCS

C

SIDE FRAME



2PCS

D

CROSSBAR



6PCS

HARDWARE IDENTIFICATION

1

BOLT
(1/4" x 12mm BLK)



12PCS

3

CAP
(25 x 25mm BLK)



4PCS

2

SUCTION CUP
(9mm)



18PCS

4

ALLEN WRENCH
(4mm)




1PC

ITEM: 720229


ASSEMBLY INSTRUCTIONS

STEP 1

Do not tighten until each step is completed or instructed.



STEP 2




COMPLETE



ITEM: 720229 ASSEMBLY INSTRUCTIONS

Product Size : 1200 X 400 X 813 H (MM)

Product Size : 47.25" X 15.75" X 32"



Note : Dimension tolerance $\pm 5\%$