


亿威 25.07.07

145.00 mm

210.00 mm

INSTRUCTIONS FOR USE

Oil-Filled Radiator



ITEM NO.: 36205HOR0-BLACK

36205HOR0-WHITE

MODEL NO.: ZOH205A




Scan the QR code to get in
touch with the service team



Email: service@electacticshop.com



Web: www.electacticshop.com



INTENDED USE

This product is intended ONLY for indoor household or office use.

It is NOT intended for industrial or commercial use. Do not use the product outdoors.

IMPORTANT INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, injury to persons, and hyperthermia, including the following:

1. Read all instructions before using this heater.
2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
3. Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
4. Always unplug heater when not in use.
5. Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
6. Do not use outdoors.
7. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
8. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange

cord away from traffic area and where it will not be tripped over.

9. To disconnect heater, turn controls off, then remove plug from outlet.

10. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.

11. To prevent a possible fire, do not block air intake or exhaust in any manner. Do not use it on soft surfaces, like a bed, where openings may become blocked.

12. A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

13. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

14. Always plug heaters directly into a wall outlet/receptacle. Never use it with an extension cord or relocatable power tap (outlet/power strip).


15. Hyperthermia can result in death. Symptoms of hyperthermia include high body temperature, headache, nausea, vomiting, tiredness, dizziness, fainting, and rapid pulse. If you begin to experience symptoms related to hyperthermia, turn off the heater and seek medical attention.

16. To avoid excessive room temperatures which can cause hyperthermia: DO NOT leave product running unattended in a confined space around infants, or individuals with reduced physical, sensory, or mental capabilities.

SAVE THESE INSTRUCTIONS

UNIT INTRODUCTIONS

Constructions




Packing List

No.	Description	Quantity
1	Oil-filled radiator body	1pc
2	Wheel base assembly	2pcs
3	Wing nut	2pcs
4	Screw	2pcs
5	User manual	1pc

ASSEMBLY INSTRUCTIONS

1. Turn the radiator upside-down on a scratch-free and stable surface to prevent damage to the paint finish or your floor surfacing(see Fig 1).
2. Fit the rear wheel base assembly into the fixed U-bolt, then screw the two wing nuts onto the U-bolt tightly (see Fig.2 - 3).
3. Fix the front wheel base assembly at the bottom of front panel by two screws (see Fig. 4).

WARNING: Only operate the radiator in normal upright position with wheels assemblies attached to the bottom (wheels on the bottom, controls on the top), any other position could create a hazardous situation.



If you are in any doubt about installing this product, consult a qualified electrician.

OPERATING INSTRUCTIONS

1. Place the product in an upright position on a flat, steady, stable, heat-resistant surface. Make sure there is nothing flammable or heat sensitive within 1 meter (40 inches). Operating the product in any other position could cause a hazard.
2. Insert the plug into a suitable wall outlet after turning the thermostat knob counter-clockwise to the minimum position and setting the power switch to "0" for off. The heater is suitable for operation on an A.C. electricity supply having the same voltage as that show on its rating label.
3. Turn the power switch from "0" to either "●" (Minimum heating), or "●●" (Medium heating) or "●●●" (Maximum heating).
4. Turn the thermostat knob clockwise to maximum position. To adjust the room temperature: turn the thermostat clockwise to raise the temperature, or counter-clockwise to lower it.
5. To turn off the heater, set the power switch to "0" position. Unplug the product from the electrical outlet when it is left unattended or is not in use.

Tip-over protection

This heater is protected with a safety switch that turns off the appliance automatically when the heater falls over, or is at an excessive angle from the horizontal. This helps prevent accidents, and the heater will resume operation when it is put back upright.

Overheat protection

This heater is protected with overheat protection that switches off the appliance automatically in case of severe overheating. In this case, unplug the appliance, wait about 30 minutes for it to cool and remove any possible cause of overheating, eg. something covering the heater. Check for damage to the appliance, the cord and the plug. If there is no damage, plug the unit back in and switch it on as described above. If the heater still does not turn on, please contact Customer Service for assistance.

MAINTENANCE AND CLEANING

The appliance should be regularly cleaned when in use in accordance with the following instructions:

1. Unplug and let the appliance cool before cleaning.
2. Gently clean the outside surface and the control panel of the appliance with a damp lint-free soft cloth.
3. If dust is present within the slits of the device, it is recommended to blow them through the use of a vacuum cleaner, a blower .
4. Do not use harsh detergents, chemical cleaners or solvents as they may damage the appliance feet.

STORAGE

1. Keep the original packaging to disassemble the appliance and store it.
2. Keep the appliance in a dry and clean place.
3. Store the unit out of reach of children.



Thank you for purchasing this product! If you have any question about the product, such as missing parts, damaged products, product assembling, and operation, please contact us via customer service email: service@electacticshop.com

ROWAN ELECTRIC APPLIANCE LLC
Email: service@electacticshop.com