


Notebook-Tisch Bambus mit Belüftungslöcher

*Wooden computer desk
with ventilation holes*



Sehr geehrte Kundin, sehr geehrter Kunde,

vielen Dank, dass Sie sich für ein Produkt aus unserem Hause entschieden haben. Um möglichst lange Freude mit dem Produkt zu haben und um einen sicheren Umgang damit zu gewährleisten, beachten Sie bitte unbedingt, die umseitig folgende Aufbau-bzw. Bedienungsanleitung. Bitte bewahren Sie diese Anleitung zum späteren Nachschlagen auf.

Bestimmungsgemäße Verwendung

Dieser höhenverstellbare und faltbare Betttisch ist nur für den Innenbereich bestimmt. Verwenden Sie das Produkt nur für seinen vorgeschriebenen Zweck. Für entstandene Schäden aufgrund von einer nicht bestimmungsgemäßen Verwendung übernimmt der Hersteller keine Haftung. Jegliche Modifikation am Produkt kann die Sicherheit negativ beeinflussen, Gefahren verursachen und führt zum Erlöschen der Garantie.

Warnhinweise

Dieses Produkt ist nicht zur Unterstützung von Computerbildschirmen oder Fernsehern geeignet.

Dieses Produkt ist nicht als Kletterhilfe zu verwenden.

Kinder sollten beaufsichtigt werden, um sicherzustellen, damit sie nicht mit dem Gerät spielen.

Nur in aufrechter und stabiler Position verwenden.

Von Wärmequellen und Feuchtigkeit wie Kaminen, Heizkörpern und Duschen fernhalten.

Achten Sie beim Auf- und Zuklappen darauf, keine Extremitäten in den Scherenfüßen einzuklemmen.

Überlasten Sie den Tisch nicht, da dies zu Schäden am Produkt oder Verletzungen führen kann. **Überschreiten Sie nicht ein maximales Gewicht von 10 kg.**

Seien Sie besonders vorsichtig, wenn Sie den Tisch mit den darauf befindlichen Gegenständen bewegen.

Üben Sie keinen übermäßigen Druck auf die Scharniere oder Gelenke aus.

Prüfen Sie alle Schraubverbindungen auf festen Sitz und überprüfen Sie diese regelmäßig.

Entsorgung:

Am Ende der langen Lebensdauer Ihres Artikels führen Sie bitte die wertvollen Rohstoffe einer fachgerechten Entsorgung zu, so dass ein ordnungsgemäßes Recycling stattfinden kann. Sollten Sie sich nicht sicher sein, wie Sie am besten vorgehen, helfen die örtlichen Entsorgungsbetriebe oder Wertstoffhöfe gerne weiter.

Intended Use

This height adjustable and foldable desk is intended for indoor use only. Use the product only for its designed purpose of use. Manufacturer will not assume any responsibility in case of damages cause of an unappropriated use. Any modification applied by customer on the original product will have a negative impact on its safety, cause danger and warranty will be canceled.

Warnings

This product is not suitable for supporting large computer monitors or TVs.

This product is not intended to be used as a climbing structure.

Children should be supervised to make sure they do not play with the product.

Only use in an upright and stable position.

Keep away from heat sources and moisture such as fireplaces, radiators and showers.

When folding and unfolding, take care not to trap extremities in the scissor-action desk legs.

Do not overload the desk as this may result in damage to the product or personal injury. Do not exceed maximum weight capacity of 10 kg.

Take extra care when moving the desk with items on top.

Do not exert excess pressure on the hinges or joints.

Check all screw connections for tightness and check them regularly.

Disposal:

Once item end-of-life, please dispose valuable raw materials for a proper recycling. If you are not sure how to handle it in a correct way please contact your local disposal or recycling centers for advice.

Usage

Unfold the desk legs and adjust them to the desired height using the wing nuts. Tighten to secure.

Adjust the deck plate according to the desired position by using the metal support.

The magnetic catch keeps the desk lid firmly closed when being used in a flat position.

Care



Check all parts for signs of wear. If any problems are detected, do not use the product. Always replace all parts with original replacements according to the manufacturer's guidelines.

For cleaning use a sponge and warm soapy water. Do not use solvent based-cleaners or detergents for example Bleach those can damage the product.



If the product is not properly cared for and maintained, it can become unsafe and can also become damaged. This can lead to dangerous situations.

Regular maintenance on the product helps to make the product safe and will also increase its lifespan.



1



2



3



4

