

DINING TABLE

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME	10 MINUTES
---------------	------------

PARTS IDENTIFICATION

A




TABLE TOP

1 PC

B




TABLE LEG


4 PCS

HARDWARE IDENTIFICATION



1		BOLT	8 PCS
2		LOCK WASHER	8 PCS
3		FLAT WASHER	8 PCS
4		ALLEN WRENCH	1 PC

ASSEMBLY INSTRUCTIONS

STEP 1 :



STEP 2 :



COMPLETE ASSEMBLY

