

WINE CABINET


USER MANUAL



INTRODUCTION

Thank you for purchasing our products.Committed to providing customers with the best quality products and service has always been our lifelong goal. Before using the product, please read this instruction manual carefully to ensure correct use. Keep the instruction manual in a place where the user can find it at any time.






PRECAUTIONS

1.There are many components and accessories in the package. Each component and accessory is labeled with a letter or a number, check carefully before using any of them. Keep them away from children to prevent accidents.
2.Please install the product on a clean and soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
3.The main components of the product is relatively heavy. Please pay attention to safety during installation.
4.The product is not stable during installation. Please do not move it randomly before it is completely installed.
5.If you have any questions during installation, please contact the customer service in time.
















***PLEASE BE SURE TO FOLLOW THE INSTALLATION STEPS IN THE MANUAL TO AVOID UNNECSSARY LOSSES CAUSED BY IMPROPER INSTALLATION.**
***IF YOU NEED FUTHER ASSIATANCE,PLEASE CONTACT THE CUSTOMER SERVICE ONLINE.**

PANEL LAYOUT































Due to the large number of boards,in order to facilitate the installation,please place the boards in order after opening the parcel and then start the installation.

HARDWARES LIST

C  71PCS	D  71PCS	E  46PCS	F  16PCS	G  8PCS
H(14mm)  38PCS	I  2PCS	J  2PCS	K  1PCS	L  1PCS
M  x2 x2 x2 x2		N  18PCS	O(20mm)  18PCS	P  6PCS
Q  5PCS	R  71PCS	A  x4 = A  x4 = A1  x4 + A2  x4		


PARTS LIST


1  1PC	2  1PC	3  1PC	4  2PCS	5  2PCS
6  1PC	7  1PC	8  1PC	9  1PC	10  1PCS
11  1PCS	12  1PC	13  1PC	14  1PC	15  1PC
16  1PC	17  1PC	18  2PC	19  2PC	20  2PC
21  2PCS	22  2PCS	23  1PC	24  4PC	25  2PCS
26  2PCS	27  4PCS	28  1PCS	29  5PCS	30  2PCS

TIPS

1. When installing the product, use a soft surface (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tightness of the screws.
3. Do not use any glue.
4. The product is unstable before it is assembled. Please pay attention to the product instal-
   lation sequence, and align all screws and screw holes before tightening.
5. The structure of this product can not meet the requirements of children climbing.


Installation method of three
in one rod and buckle






1


HOW TO SPLIT THE SLIDE RAIL



2


You will need	
A1x2	Fx4






3

You will need	
Cx4	Dx4
Ex4	Rx4




4


You will need	
Cx4	Dx4
Ex4	Rx4



5


You will need	
Cx4	Dx4
Ex4	Rx4






6


You will need	
A1x2	Fx4







7

You will need	
Cx8	Dx8
Ex8	Rx8






8




9

You will need
Hx24





10



11


You will need	
Cx8	Dx8
Ex8	Rx8






12

You will need	
Cx8	Dx8
Ex8	Rx8




13


You will need	
Hx6	Px6
Lx1	



14


You will need	
Cx3	Dx3
Rx3	






15


You will need	
Cx6	Dx6
Rx6	




16

You will need	
Cx2	Dx2
Rx2	






17




18

You will need	
Cx6	Dx6
Rx6	




19

You will need	
A2x4	Fx8




20

You will need
Gx8




21

You will need	
Ix2	Jx2




22


You will need	
Cx8	Dx8
Rx8	



23




24




25

You will need	
Cx4	Dx4
Rx4	




26

You will need	
Cx4	Dx4
Rx4	




27

You will need	
Nx18	Ox18




28

You will need	
Hx4	Qx5





29


You will need	
Hx2	Kx1




You will need
Mx2










31

INSTALLATION COMPLETED



INTRODUCTION

Thank you for choosing Kitchen Pantry. Please read the instructions carefully and keep them for future reference. If you need further assistance, please contact our customer service online via email.

PRECAUTIONS

1. When installing the product, use a soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tightness of the screws.
3. Do not use any glue.
4. The product is unstable before it is assembled. Please pay attention to the product installation sequence.
5. The structure of this product can not meet the requirements of the placement of heavy items and children climbing.

WARRANTY

We offer an **18-month** warranty after the original purchase date. If there are manufacturing defects on this product, please contact support by email with your order number and other details about the problem.