













Assembly Instructions





Accessories

1-Left Side Panel	1PC	2-Right Side Panel	1PC
			
3-Cross Leg	2PCS	4-Left Back Panel	1PC
			
5-Right Back Panel	1PC	6-Top Panel	1PC
			

7-Bottom Panel	1PC	8-Shelf	2PCS
			
9-Left Door	1PC	10-Right Door	1PC
			



CAUTION


An assistant is required

CUSTOMER FIRST, SERVICE FOREMOST!


Questions? Issues?

CONTACT US


REPLY WITHIN 24 HOURS IN BUSINESS DAYS




Step 1: Put two cross legs 3
on a flat surface




Step 2: Insert the cross legs 3 into the bottom of left side panel 1





Step 3: Insert the cross legs 3 into the bottom of right side panel 2






Step 4: Fix side panels 1, 2 and cross legs 3 with 4 screws A





Step 5: Install left back panel 4 and fix it with left side panel 1 by 3 screws A




A*6




M5*12MM

Step 6: Install right back panel 5 and fix it with left back panel 4 and right side panel 2 by 6 screws A



Step 7: Put top panel 6 on the top





After the screws are tightened in the subsequent step, the top panel will be properly aligned

A*10




M5*12MM

Step 8: Fix top panel 5 with
other parts by 10 screws A






Step 9: Tilt the bottom panel 6 into the cabinet and put it on the cross legs 3



E*2		
 M8	 M5*30MM	 M5

Step 10: Fix the cabinet on the wall with 2 expansion screws E to prevent tipping

If the ground is uneven, it can be adjusted by rotating the screw. This will fix the situation where the door is not easily opened or closed.




DANGER





Always secure this furniture with an anchor device.

Unsecured furniture can cause serious injury or death to children.

Never allow children to stand, climb or hang on drawers, doors or shelves.

Never open more than one drawer or door at a time.

Place the heavy items on the lower position.


Never place a television on this furniture.

This is a permanent label. Do not remove!


C*8




Step 11: Install 8 shelf clasps C on the side panels (The height can be adjusted as your needs)



Step 12: Put two shelves 8
on the shelf clasps




G*2	H*2	Step 13: Insert the door pivots G into the hole of the bottom corners (0/1 shim H can be used to adjust the seam), then insert the doors 9 and 10 into the pivots at the bottom and adjust the spring shafts at the top corners
		



There are two holes here, and G should be inserted into the smaller hole.

B * 4	F * 2	Step 14: Install 2 handles F on the doors with 4 screws B
 M4		



D * 4



Step 15: Install 4 magnets D
on the doors as shown

