



Model		S0	S1	S2	S3	S4
Serial No.	Accessory Name					
①	Bottom Panel	1	1	1	1	1
②	Side Panel	2	2	2	1	0
③	Side Basket Side Panel	0	0	0	1	2
④	Front Panel	2	2	2	2	2
⑤	Top Cover	0	0	1	1	1
⑥	Handle	0	0	1	1	1
⑦	Main Body of Side Basket	0	0	0	1	2
⑧	Left Side Panel of Side Basket	0	0	0	1	2
⑨	Right Side Panel of Side Basket	0	0	0	1	2
⑩	Silent Lockable Caster	0	0	2	2	2
⑪	Silent Caster	0	0	2	2	2
⑫	Lockable Caster	0	2	0	0	0
⑬	Caster	0	2	0	0	0
⑭	Lid Ring	1	1	0	0	0



Installation Steps (Model S4-Most Complex Model)



1. Place the base on a flat surface with the concave side facing up, insert the ③ side panels, and press firmly.


2. Then insert the side panel on the other side.

3. Take out the 4 front panels, align the hooks on both sides with the hooks on the side panels.

4. After aligning both sides, insert them into the base and press firmly.



5. Insert the other side panel using the same method.




6. ⑤ Align the top ring with lid and press it down into place.



7. Insert the handle into the notch of the round hole from below and press firmly.



8. Take out the ⑦ main body of the side basket.




9. Insert the ⑦ main body of the side basket together with the left ⑧ and right side basket side panels ⑨ by aligning the holes.



10. Push the assembled side basket out from the inside to the outside.



11. Align it with the outer round holes and insert it into place.




12. Flip the product over, then insert the four caster into the holes respectively. Installation completed.

Disassembly Steps




1. First remove the side basket.




2. Lay it gently on its side and pull out the four caster.



3. Open the lid.



4. Put your feet inside to hold it steady, place both hands on the handles and pull up firmly.



5. Take out the front panel and other panels. Disassembly is completed.