

INSTRUCTIONS & CAUTIONS CITYSCAPES™ 15 20 25

FOR CITYSCAPES™ PRODUCT NUMBERS:

CCS-150, CCS-200, and CCS-250.

WARNING: To minimize the risk of serious injury or death from fire or explosion, read and follow all instructions and safety precautions below when using your Coleman® Cityscape™ Fire Pit.

Safe Location:

- Only use outdoors (with no cover) under adult supervision.
- Keep children and pets a safe distance away from fire pit while in use.
- Do not use on a boat or in an RV.
- Only use on a non-combustible surface.
- Keep away from bushes, shrubs, and tree branches.
- Always use with the feet installed, especially on lawns or grass.
- Do not use liquid fire starters or lighter fluid to start fire.
- Only use 100% wood pellets or firewood as fuel.
- Keep gasoline and other flammable substances away from fire pit.
- Do not place objects against fire pit.

For Safe Use:

- Do not touch fire pit, embers or ash until completely cool.
- Use caution when leaning over fire pit.
- For best results, do not place wood above top air vent holes.
- Do not use water to extinguish the fire.
- Do not use fire pit if damaged or broken.
- Cover fire pit when not in use.

Limited 2 Year Warranty. Back Home Products warranty each and every Coleman® Cityscape™ product to be free of manufacturing defects, and we will replace with a new product, at our option, any genuine Coleman® Cityscape™ product sold by an authorized retailer, with proof of purchase by the original owner, that is deemed defective. Back Home Products does not warranty its products against normal wear or misuse. If your Coleman® Cityscape™ product was damaged due to misuse, our customer service team can analyze the damage and may be able to suggest options for the customer to remedy. If your Coleman® Cityscape™ product is unable to be repaired after misuse, we will extend a one-time courtesy offer, allowing you the option to purchase a new Coleman® Cityscape™ product for 50% off of our original MSRP price (excludes sale pricing) on Back Home Products website on a new identical Coleman® Cityscape™ product. Warranty claims are not applicable for countries outside the U.S. and Canada.



Distributed by:
Back Home Products, Inc.
8321 E. Evans Road, Suite 101
Scottsdale, AZ 85255

CUSTOMER SERVICE:

Contact Back Home Products at 833-953-9696, info@colemanbackhome.com, or on our site at colemanbackhome.com

Coleman® is a registered trademark used under licensed.



INSTRUCTIONS & CAUTIONS

CITYSCAPES™ 15 20 25

ASSEMBLY

