


WALL CLOCK USE EXPLAIN

- (1) Install beattery:please open the back cover,identify the sign place the clock will working,if not the clock can not work.
- (2) working precision in the electrical source1.3v-1.5v
- (3)Take down the clock,fix the hour hand and the minute hand one by one.tips:press the hands into the clock axis with 2 fingers let they both point to 12 o'clock, check if the hour and minute hands are parallel,and tighten the nut if there's no problem

CLOCK USE



USE"AA"SIZE
BATTERY (NOT INCLUDE)



- 1.Install the hour wheel
at 12 o'clock direction



- 2.Install the minute hand
at 12 o'clock direction



- 3.Install the second hand
at 12 o'clock direction