
# ASSEMBLY INSTRUCTIONS




# LIVING ROOM CHAIR

## Be sure to keep spare parts.

**If screws or nails of a product are damaged or lost,
or screws or nails of a subsequent product are
damaged or aged, spare parts can be used to replace them.**


**1**



Ax(L)



Ax(R)





Bx2




Dx4

Please install screw **D** to **50%**
and tighten it to **100%**
after the four screws are installed



**2**



Cx1





Ex6




Fx6

Please install screw **F** and accessory **E** to **50%**
After the four screws are installed
tighten them up to **100%**







# SPARE PARTS



Ax(L)




Ax(R)



Bx2

Please note that parts A
have left and right distinctions!



Cx1



Dx4+1extra
(M6*45mm)



Ex6+1extra
(M8*50mm)




Fx6



Gx1

# ASSEMBLY INSTRUCTIONS



## LIVING ROOM CHAIR


**Be sure to keep spare parts.**

If screws or nails of a product are damaged or lost,
or screws or nails of a subsequent product are
damaged or aged, spare parts can be used to replace them.

**1**




Please install screw **D** to **50%**
and tighten it to **100%**
after the four screws are installed








**2**





Please install screw **F** and accessory **E** to **50%**
After the four screws are installed
tighten them up to **100%**



## SPARE PARTS




Please note that parts A
have left and right distinctions!

