


Inflatable Double Water Slide



Instruction Manual

SKU: QNCE1011



Size:

17.7 ft L × 11.8 ft W × 7.2 ft H



Age Range:

3–10 Years



Max Occupancy:

Up to 6 Children




For Domestic Use Only



Please read before use and keep for future reference.



Important Safety & Product Overview




Important Safety Information

- Adult supervision required at all times.
- For children ages 3–10 only.
- Up to 6 children at one time.
- Remove shoes, eyeglasses, jewelry, and sharp objects before play.
- Use only on soft, level ground such as grass.
- Do not use in winds over 20 mph.
- Keep children away from the blower and power cord.
- Always slide feet first.
- For domestic outdoor use only.

Package Contents



Inflatable Slide



Blower



Water Hose Assembly



Ground Stakes



Repair Kit



Carry Bag



Instruction Manual



Read all instructions before setup and use.



Set-Up & Water Tube Connection




1 Choose Location

Place the slide on a flat grassy area at least 6 ft away from fences, trees, walls, and other obstacles.




2 Unroll the Slide

Spread the inflatable out fully and make sure the splash pool lies flat.



3 Connect the Blower

Attach the inflation tube securely to the blower and place the blower on a stable dry surface.




4 Anchor the Unit

Insert the ground stakes through the anchor points of the slide and blower.




5 Inflate the Slide

Turn the blower ON and allow the product to fully inflate before use.



6 Connect Water Tube

Attach the spray tube along the arch and slide, then connect a regular garden hose with the included adaptor. Turn on water gradually.



Water Play Notes



Continuous blower operation is required during use.



Check all anchors before children begin playing.



Adjust water pressure gradually until the sprayers reach the desired flow.



Add a shallow amount of water to the splash pool before play.



Double-check stakes, blower connection, and water tube before use.

Take Down, Maintenance & Repair



1 Take Down

1. Turn water OFF and drain the splash pool.
2. Allow the unit to dry fully. If needed, run the blower for 20–30 minutes after draining to help remove moisture.
3. Switch the blower OFF and unplug it.
4. Remove the stakes and detach the inflation tube from the blower.
5. Fold the product neatly and roll it tightly.
6. Store the product and accessories in a dry place.



2 Maintenance

- Inspect seams, straps, stakes, and the blower before each use.
- Clean the inflatable with mild soap and water only.
- Do not use bleach, chlorine, or harsh chemicals.
- Do not store the product when wet or damp.
- Keep the blower dry and never immerse it in water.



3 Minor Repair

- Turn the blower OFF and deflate the product completely.
- Hand-sew small tears if necessary.
- Apply a repair patch to the outer layer only.
- Allow the repaired area to dry before reuse.



For domestic use only. Keep this manual for future reference.