






LEXINGTON®

H O M E B R A N D S

ASSEMBLY INSTRUCTIONS

415-877 Vernon Hills Rectangular Dining Table

PART	HARDWARE LIST	QTY
A	 Bolt $\text{\O} \frac{5}{16}'' \times 4''$ ($\text{\O} 8\text{mm} \times 100\text{mm}$)	8 PCS
B	 Lock Washer	8 PCS
C	 Flat Washer	8 PCS
D	 Wrench	1 PC



For additional consumer assistance please contact your Lexington dealer or call our Consumer Services Department at 1-336-474-5300, Monday-Friday, 8-5 Eastern

LEXINGTON®

H O M E B R A N D S

ASSEMBLY INSTRUCTIONS

415-877 Vernon Hills Rectangular Dining Table

To Assemble Table:

1. Place table top upside-down on flat, clean, non-marring surface.
2. Insert (1) Leg into corner block of table top. *NOTE: There is a filler block in the corner of the table top to ensure proper leg orientation. The leg is beveled on that side to align with the filler block. The metal T-nuts in the leg face the outside of the table as shown above in the "Top View of Corner Block & Leg."*
3. Use wrench (D) to attach (1) Leg to Top with (2) of each: Flat Washers (C), Lock Washers (B), and Bolts (A). Fully tighten both bolts. Repeat steps 2-3 for other (3) Legs.
4. Return assembled table to its upright position and place in desired location.

To Attach Leaf:

1. Open table locks on underside of table, located between half-tops on each side.
2. Pull on one end of table to separate half-tops. Open table enough to insert leaf.
3. Place table leaf between half-tops so that pins on leaves align with holes on half-tops.
4. Push table on each end until fully closed.
5. Close table locks on underside of table between each leaf and half-top.