


L30×W15×H70.9 INCH




Important!






Thank you for your purchase. Please open it carefully.

If you encounter any problems, please contact us.





Service tenet - to enable customers to enjoy high-quality service.

F L Y








PARTS LIST		LISTE DES PIÈCES				LISTA DE PIEZAS			
Nom Nombre		Part Piece Pieza	Qty Qte	Spare	Name Nom Nombre		Part Piece Pieza	Qty Qte	Spare
A	Left Back Panel		1		M	Wheel mounting plate		2	
B	Right Back Panel		1		N	Wheel		4	
C	Left Side		1		O	Shelf Support		16	2
D	Right Side		1		P	Laminate fastening buckle		16	2
E	Kick Plate		1		Q	Door Pivot Pin Shim		2	2
F	Bottom Panel		1		S	Magnet		4	
G	Top Panel		1		T	Set screw		1	
H	Shelves		4		a	Right-side door rubber cover		2	
I	Left Door		1		b	Fixed caster screws		16	1
J	Right Door		1						
K	13/32"Screw		4						
L	13/32"Screw		39	2					

1




 K×4

2




 L×8

3






4





L×4

5




The four corners of the top need to include the four corners of the side panels

6




L×8

7




8




 L×4

9




 L×14

10




 b×16

11





 O×16

12




 P×16

13




S×2

14




a×2





S×2

15



16

The cabinet can be fixed to the wall as needed.



Problems and Solutions

When the door is closed, it still protrudes outward.

That's because the door is made of steel plate and has stretchability.
You can adjust it according to the method shown in the picture.

