

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION : 4 DRAWER MEDIA UNIT




1

Reverse the Media unit & place the leg as shown & align the leg to match the apron.




Insert the Bolt to fix the leg with the Media unit top and tighten the nut with the washer as shown in fig1

2



3

Fix the other pair of legs in the similar way



Reverse the unit straight. Now your Media unit is ready for use

4



Fig. 1

