


ASSEMBLY INSTRUCTION

ITEM NO. N715P255909

Dining Chair



ASSEMBLY INSTRUCTION

ITEM NO. N715P255909

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners

ASSEMBLY INSTRUCTION

ITEM NO. N715P255909




ASSEMBLY INSTRUCTION

ITEM NO. N715P255909


Part List

A




CHAIR BACK (1pc)

B



SEAT CUSHION (1pc)

C




FRONT LEGS (2pcs)

ASSEMBLY INSTRUCTION

ITEM NO. N715P255909

Hardware List


①



Ø1/4"*L51mm

BOLT (8pcs)


②



Ø1/4"*L38mm

BOLT (2pcs)


③



Ø1/4"*13mm

SPRING WASHER (10pcs)

④



Ø1/4"*19mm

FLAT WASHER (10pcs)

⑤




4mm

ALLEN WRENCH (1pc)

ASSEMBLY INSTRUCTION


ITEM NO. N715P255909

STEP 1 :



BOLT	BOLT	SPRING WASHER	FLAT WASHER	ALLEN WRENCH
Ø1/4"×51mm	Ø1/4"×38mm	Ø1/4"×13mm	Ø1/4"×19mm	4mm
				
① x 4	② x 2	③ x 6	④ x 6	⑤ x 1

STEP 2 :



BOLT	SPRING WASHER	FLAT WASHER	ALLEN WRENCH
Ø1/4"×51mm	Ø1/4"×13mm	Ø1/4"×19mm	4mm
			
① x 4	③ x 4	④ x 4	⑤ x 1

ASSEMBLY INSTRUCTION

ITEM NO. N715P255909

COMPLETE

