

# ASSEMBLY INSTRUCTIONS

## DINING CHAIR

ASSEMBLY  
REQUIREMENTS

2-Person  
Assembly

1 Hour  
Assembly Time  
Approximate

Tools Required  
(Not Provided)



Philips Screwdriver



Mallet

### Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product. Contact our customer service department in case there are any missing or damage parts or hardware. Replacement parts are normally shipped within 2 or 3 days.

**PRODUCT PURCHASED THROUGH OUR AUTHORIZED VENDORS ONLY ARE ELIGIBLE FOR REPLACEMENT PARTS**

**We appreciate your business!**

**THIS PRODUCT IS FOR INDOOR AND HOUSEHOLD USE ONLY- NOT FOR COMMERCIAL USE.**



### ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List. Ensure parts and hardware are complete before assembling the product. Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

### SAFETY PRECAUTION

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

### TIPS FOR ASSEMBLY

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

### CARE AND MAINTENANCE

- Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
- Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.
- Solid wood is impacted by heat and humidity fluctuations which may cause small joint separations or hairline cracks; place the furniture away from direct sunlight and air conditioning vents, heating vents or units to protect the furniture.


# ASSEMBLY INSTRUCTIONS

## DINING CHAIR

### PART LIST (FOR 1 COMPLETE CHAIR)


Item	Description	Part	Qty
1	Chair Body		1
2	Leg Left		1
3	Leg Right		1
4	Front - Apron(Long)		1
5	Back - Apron (Short)		1

### HARDWARE LIST (FOR 1 COMPLETE CHAIR)

Item	Description	Part	Qty	Extra
A	JCBC M6 X 45mm		4	1
B	JCBC M6 X 60mm		4	1
C	Spring Washer M6 X 13mm		8	2
D	Wood Dowel M8 X 35mm		8	2
E	Allen Key		1	
F	LEG STUD		4	2

\* EXTRA HARDWARE FOR SPARE USE \*

## STEP 1




- Place Left Leg (2) as shown and insert Wood Dowel (D) into the two outer holes.
- Attach Front and Back Apron (4 & 5) to (2) - note that (5) is placed near to the hole marking on (2) and the screw holes of (4) & (5) are facing inwards towards each other.
- Insert Screw (A) fitted with Spring Washer (C) to fasten (4 & 5) to (2). Use Allen Key (E) to tighten (A) gently at this time. Next, insert Wood Dowel (D) into the two outer holes on the top edge of (4 & 5).
- Attach Right Leg (3) to (2) via wood dowels on (4 & 5).
- Insert Screw (A) fitted with Spring Washer (C) to fasten (3) to (4 & 5). Use Allen Key (E) to tighten (A) gently.

## ASSEMBLY INSTRUCTIONS

### DINING CHAIR


#### STEP 2

Place assembly from STEP 1 right-side up on a flat, level surface and level the legs. Next, tighten all of the Screws (A) on Front and Back Apron fully. Do not over-tighten the screws.



#### STEP 3

- Place Chair Body (1) bottom-side up on an elevated surface (e.g. table top) as shown.
- Position leg assembly from STEP 2 as shown and align the screw holes on Left & Right Legs to the screw holes on the bottom-side of the seat. (Note: the Hole Marking is towards the rear edge of the seat.)
- Insert Screw (B) fitted with Spring Washer (C) to fasten (1) to Left & Right Legs
- Use Allen Key (E) to drive (B). Do not tighten (B) completely until both screws are in place on each leg. Do not over-tighten the screws.
- Use a mallet or hammer to gently nail Leg Stud (F) into each end of the leg.



Position the chair right-side up. The assembly of the Chair is complete.