JAMIE YOUNG Co

Large Trinity Wall Sconce
4TRIN-LGLV

SAFETY, INSTALLATION & CARE INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

We strongly recommend that all direct-wired lighting products be installed by a licensed electrician.

DO NOT EXCEED the rated bulb wattage. **Keep flammable materials away from bulbs.** This light fixture is shipped with all internal wiring intact. Do not open the product or alter the wiring in any manner.

WARNING: Be certain that the power to the electrical junction box is turned off at the circuit breaker before installation. Turning the power off at a light switch is not sufficient to prevent electrical shock.

CAUTION: Prior to installation, locate ALL PARTS INCLUDED before disposing of packaging materials.

Tools Required for Installation (not included):

Phillips and Flat-blade Screwdrivers	Drill
Pliers	
Electrical Tape	

Parts Required (not included):

Part	Qty.	Description
(A)	1	Junction Box
(B)	1	Neutral Junction Box Wire
(C)	1	Ground Junction Box Wire
(D)	1	Hot Junction Box Wire

Hardware and Parts Included:

Part	Qty.	Description	Part	Qty.	Description
(E)	1	Ground Wire	(P)	2	Agate Piece 1
(F)	1	Hot Fixture Wire	(Q)	2	Gasket
(G)	1	Neutral Fixture Wire	(R)	8	Plastic Gasket
(H)	3	Wire Connector	(S)	4	Threaded Metal Post
(I)	1	Ground Screw	(T)	2	Agate Piece 3
(J)	1	Mounting Bracket	(U)	1	Agate Piece 2
(K)	2	Screw	(V)	4	Knurled Nut
(L)	1	Back Plate	(W)	2	Expansion Screw
(M)	6	Flat Head Screw	(X)	2	Mounting Screw
(N)	2	Socket	(Y)	1	Fixture Body
(O)	2	Light Bulb (Not Included)			

Important Safety Instructions:

This product must be installed in accordance with the applicable installation codes by a person familiar with the construction and operation of the product and the hazards involved.

This fixture has been rated for up to two (2) 40W-maximum Type B incandescent light bulbs (not included). To avoid the risk of fire, do not exceed the recommended wattage. This fixture is meant for indoor use & is approved for use in covered outdoor areas or bathrooms.

JAMIE YOUNG Co

Large Trinity Wall Sconce
4TRIN-LGLV

SAFETY, INSTALLATION & CARE INSTRUCTIONS

WARNING:

Do not touch the bulb when the fixture is turned on. Do not look directly at the lit bulb.

Keep flammable materials away from the lit bulb.


To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug the fixture and allow it to cool prior to replacing the light bulb

INSTALLATION PROCEDURE: Refer to Figure 1.

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Carefully unpack all fixture parts and hardware and lay them out on a clean work surface.
3. Use wire strippers to prepare the ends of the two wires so that there is about 1/2" of exposed wire for the Wire Connectors (H).
4. Carefully inspect the fixture wires. The Neutral Fixture Wire (G) is white. The Hot Fixture Wire (F) is black, and the Ground Wire (E) is green.
5. Attach the Ground Wire (E) from the fixture to the Ground Junction Box Wire (C); it usually has green insulation around it or is bare wire. Fasten them together with a Wire Connector (H) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. If your Junction Box (A) does not have a Ground Junction Box Wire (C), insert the Ground Screw (I) into the Mounting Bracket (J) where it is marked “Ground”, and wrap the fixture’s bare ground wire around the Ground Screw (I). Tighten the screw to clamp the Ground Junction Box Wire (C) between the Ground Screw (I) head and the Mounting Bracket (J). It is imperative that the Junction Box (A) in your home be properly grounded.
6. Connect the Neutral Fixture Wire (G) to the Neutral Junction Box Wire (B); it usually has white insulation around it. Fasten them together with a plastic Wire Connector (H) and wrap the connection with electrical tape. Make sure that no wire strands are exposed.
7. Connect the Hot Fixture Wire (F) to Hot Junction Box Wire (D); it usually has black insulation around it. Fasten them together with a plastic Wire Connector (H) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
8. Gently tuck the wire connections neatly into the Junction Box (A).
9. Insert Expansion Screws (W) to the wall; attach the Mounting Bracket (J) to the wall outlet Junction Box (A) using the Mounting Screws (X) and Screw (K). Tighten screws with a Screwdriver until secure.
10. Fix Back Plate (L) to Mounting Bracket (J) with Flat Head Screws (M).
11. Install Light Bulb (O) (Not Included) to Socket (N).
12. Fix Agate Pieces 1 (P) to Fixture Body (Y) with Flat Head Screws (M), Threaded Metal Post (S) and Plastic Gasket (R).
13. Fix Agate Pieces 2 (U) to Fixture Body (Y) with Flat Head Screws (M), Threaded Metal Post (S) and Plastic Gasket (R).
14. Fix Agate Piece 3 (T) to Threaded Metal Post (S) with Knurl Nut (V) and Plastic Gasket (R).
15. Restore power to Junction Box (A) and test the fixture.

Large Trinity Wall Sconce
4TRIN-LGLV

Figure 1:



CARE & CLEANING:

To clean, wipe the fixture ONLY with a soft, dry cloth.

SAVE THESE INSTRUCTIONS