
# Assembly Instructions




# We're here to help!

If you have any issues with this product, please contact our customer service team **before returning** it.


We want you to be completely satisfied with your purchase! If anything is missing, damaged, incorrect, or not what you expected, don't worry. Please keep the outer packaging and take photos of both the packaging and products, and then reach out to us. We'll take care of everything and send you a free replacement, so you can enjoy your purchase as soon as possible without any hassle.


## **Assembly Instructions:**


- 1. Carefully read these instructions and keep them for future reference.
- 2. Refer to the parts list for guidance and ensure that you have all the pieces before starting the assembly process, if anything is missing, damaged, incorrect, contact us FIRSTLY BEFORE assembling.
- 3. When assembling, place all parts on a soft, clean, and flat surface, such as a carpet, to prevent any scratches.
- 4. To avoid misalignment of the holes, Please don't full tighten the screws until you ensure all parts in place.



When using the electric screwdriver, Reduce the power and torque to avoid damaging the furniture








#### (A Caution)

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge.

Contact us for free replacement if having damaged or missing parts.

## Parts & Hardware List



#### Parts & Hardware List

#### Hardware List




#### Installation of Cams and Pins

Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening

to the hole of the pin it is locking. Lock the cam by turning the cam head with a screwdriver until it


is tightened. Please do not use an electric screwdriver to assemble the unit.



Read each step carefully before starting. It is very important that each step of instruction is


performed in the correct order. If these steps are not followed in sequence, assembly


difficulties will occur.




Disconnect the rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.

Take section C out of the guide rail (note that section AB is a whole, do not pull section B ard,otherwise the guide rail will be damaged)





















8



