


ASSEMBLY INSTRUCTIONS




IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.


- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.



* Use power tools to assemble this product will invalidate any claim and damage this product making it unsafe !!!
 * Please assemble on a clean soft surface to avoid damage.
 * Please check contents and read the instructions before commencing assembly.
 * Assemble this product following the enclosed instructions carefully.
 * Please take care to avoid damaging panels during assembly.

TIP

If you wish, after assembly, use a rubber to erase part numbers "12", "13", "15" and "18".
























PARTS LIST

Please Note:

The below parts have all been stamped with the part number to help identify them during assembly.



01	Left Chest Side Panel	x1	11	Stool Crosspiece	x2
02	Front Baseboard	x1	12	Stool Seat	x1
03	Back Baseboard	x1	13	Mirror Base Panel	x1
04	Right Chest Side Panel	x1	14	Mirror Side Panel	x2
05	Back Crossbar	x1	15	Mirror Panel	x1
06	Upper Crossbar	x2	16	Drawer Side	x8
07	Right Table Side Panel	x1	17	Drawer Back	x4
08	Top Panel	x1	18	Drawer Front	x4
09	Back Panel	x2	19	Drawer Bottom	x4
10	Stool Side Panel	x2			

FITTINGS LIST

A  Flat Head Screw Ø4,0 x 14mm (24x)	B  Flat Head Screw Ø6,0 x 10mm (16x)	C  Flan Head Screw Ø4,0 x 20mm (8x)	D  Flan Head Screw Ø3,5 x 30mm (2x)
E  Flat Head Screw Ø4,0 x 50mm (22x)	F  Flat Head Screw Ø4,5 x 60mm (4x)	G  Dowel Ø6,0 x 30mm (62x)	H  Nail 10 x 10 (64x)
I  Flat Head Screw Ø3,0 x 16mm (8x)	J  Cam Bolt (18x)	K  Mirror Support (2x)	L  Cam Nut Ø15mm (10x)
M  Cam Nut Ø12mm (8x)	N  Plastic Foot (10x)	O  Hole Plugs (22x)	P  Glue (2x)
Q  Strap (2x)	R  Washer (4x)	S  Handle (4x)	T  Drawer Runners (4x)
U  Back Panel Strip (1x)			

TIPS FOR FITTINGS CAM-LOCKS


WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE






Cam bolt head needs to be in centre

CAMBOLT


Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




Pre-Assembly




Detail 1




Detail 2



Detail 3














Detail 4




Detail 5


Pre-Assembly



Detail 1





Detail 2




Detail 5

1





Detail 1




Detail 6

2





Detail 1





Detail 7

3






For your future reference
Order number should be here




Detail 8


4




1° 4X




2° 4X




3° 4X




4° 4X




5° 4X



Detail 1







Detail 12






Detail 13


TIPS FOR FIXING
DRAWER BOTTOMS





5





Detail 1




Detail 6



6





Detail 1




Detail 7

7




Counterbore



Marking




Detail 9



Detail 10




Detail 10.1





Detail 10.2


8




9



Detail 11



Detail 11.1



10




O-Hole Plugs (12x)



See last page




See last page




Detail 14

Detail 14


11

A-Flat Head Screw
Ø4,0 x 14mm (8x)

Detail 15



Drawer Adjustment



Drawer Lock

WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

