


### USE AND MAINTENANCE


- Use on level surfaces only
- Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly for safety.
- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

## Button Tufted Loveseat

### PART LIST



1 - Loveseat Base - x1




2 - Seat Cushion - x1




3 - Chair Legs -x4

### Assembly Instruction




1. Carefully remove loveseat base from carton and unpack.  
Tip the seat base over as shown.  
Align the leg post with the hole and screw in the leg clockwise until hand tight. Be careful not to overtighten. Only until snug and positioned straight.

BOTTOM





2. Turn loveseat upright on legs



3. Note seat cushion and loveseat bottom hook and loop fabric strips.

4. Align seat cushion to loveseat bottom and press down to affix seat cushion.



Congratulations!  
Setup of your new  
Button Tufted Accent  
Loveseat is complete!

