

Assembly Instructions for Model 221856435

Installation instructions for 30cm/40cm circular arc ceiling lights

1. Prepare tools

The tools required for installation include: electric drill, marking pen, hammer, electrical tape, cross screwdriver, and ladder. The electric drill bit is $\varnothing$ 8mm.



2. Make punching marks

Align the suction cup with the installation position and mark the installation hole with a marker pen. The 30 and 40 centimeter ceiling lights have two fixing holes.



3. Drilling

Drill holes at the marked locations.




4. Apply expansion rubber plugs

Use a hammer to drive the expansion plug into the drilling position.



5. Wiring

Twist wires of the same color together and connect them to household wires. It is best to wrap them with electrical tape to prevent the wire ends from falling off.



6. Fixed ceiling tray

Thread the wooden screw through the suction tray, align it with the expansion plug on the wall, and tighten it with a screwdriver.



7. Install the light bulb (not included)
After fixing the ceiling tray, screw on the light bulb.



8. Test circuit
Turn on the switch and test if the light bulb is on. The main reasons why the light bulb does not light up are: the wiring is not properly connected, and the wire ends come off; The light bulb is broken.



9. Install the lampshade
When installing the lampshade, first clip in the two fixing hooks, then pull off the spring hooks and clip in the lampshade.



Notes:

1. Please disconnect the power supply during installation and pay attention to electrical safety;
2. When installing and using ladders at heights, please pay attention to personal safety, prevent stepping on empty spaces, and prevent falling;
3. If necessary, please find a professional electrician for installation;
4. The glass lampshade is a fragile item. When clamping the lampshade, the action should be light and stable to prevent it from falling and breaking.

Your fixture is now assembled and ready to use.