

# ASSEMBLY INSTRUCTION

▽ PARTSxQTY

## ASSEMBLY PROGRAM

<p><b>1</b></p>	<p><b>2</b></p>
<p><b>3</b></p>	<p><b>4</b></p>

<p>Ax1</p>	<p>Gx4</p>
<p>Bx1</p>	<p>M6x20mm</p>
<p>Cx1</p>	<p>Hx4</p>
<p>Dx1</p>	<p>Ix1</p>
<p>Ex5</p>	
<p>Fx1</p>	