

USER MANUAL



BATHROOM VANITY MIRROR

CONTENTS



Safety Information	01-02
Product Introduction	03
Part List	04
Tools Required	05
Installation Guide	06-09
Touch Controls	10

SAFTY INFORMATION

Please read these instructions carefully before installation and retain this manual for future reference. If you require assistance, please contact our Customer Support team.

NOTICE: Strictly follow the installation steps in order. Failure to do so may result in product damage or void the warranty.

For further assistance, please contact Customer Support.



Multi-person installation


SAFTY INFORMATION

WARNING: Risk of electric shock.

Electrical wiring must be performed by a qualified professional.

- Do not place hard or sharp objects on the mirror surface. Failure to comply may result in property damage or personal injury.
- Do not expose the product to open flames or immerse it in water.
- Turn off the power during thunderstorms. Lightning strikes may damage the product's internal electrical components.
- Keep out of reach of children.
- Operate the touch sensor button with gentle pressure.
- Keep the mirror dry. Excessive moisture may reduce the sensitivity of the touch controls.
- Clean the mirror surface with a standard glass cleaner. Ensure the mirror is completely dry before operation.
- If the product will not be used for an extended period, disconnect the power and store it away from direct sunlight.
- Do not disassemble or modify this product.
- Discontinue use immediately if the product functions abnormally.
- All fittings must be installed in accordance with the latest IET/IEE wiring regulations and local building codes.
- For indoor use only. Keep the product away from curtains, drapes, and flammable fabrics. Do not cover the mirror.
- Regularly inspect the power cord, transformer, and all components for damage. If any part is damaged, discontinue use immediately.




PRODUCT INTRODUCTION



PART LIST

ID	Description	QTY
1		1
2	 8*35mm	3+1
3	 ST5*40mm	3+1

TOOLS REQUIRED (NOT INCLUDED)




ID	Description
A	
B	
C	
D	
E	
F	



Multi-person installation



WALL-MOUNTING (HORIZONTAL OR VERTICAL)

STEP 1



Select a suitable location on the wall. Use a spirit level and the mounting bracket to mark the drilling points. Drill holes at the marked positions.

STEP 2



Align the holes on the mounting bracket with the drilled holes in the wall. Using a hammer, drive the wall anchors through the bracket holes and into the wall.



STEP 3




3 X3



A X1




WARNING: Please ensure the mirror is hung stably. The mirror may detach from the hanging bracket and fall when mirror is lift upwards.




Fasten the screws into the wall anchors.
Hang the mirror onto the mounting bracket and adjust for level.

PLUG-IN OR HARDWIRED




Plug-in

Standard US plug



Hardwired

Wall Switch Supported



NOTICE: The wire terminal plate is not included.

TOUCH CONTROLS



NOTE: When powered on, the Defog button indicators will illuminate blue by default. Short-press any button to activate its function; the indicator will turn white. This mirror features a power-off memory function. When the main power is off, the light settings will be restored once power is resumed.



Defog & Indicator Light Control

Auto-off timer: 2 hours.

Short-press the button once to toggle the defog function. Regardless of the current light status, press and hold to turn off the button indicators; short-press again to reactivate them.

Note: The defog setting does not have a memory function after power off.



Front Light: Power / Dimming / Color Temperature

Short-press the button to turn on the front LED light; press repeatedly to switch color temperatures: White, Natural, and Warm. Continue short-pressing to turn off the front light.

Press and hold the button to dim or brighten the front light (10%–100%).



Back Light: Power / Dimming / Color Temperature

Short-press the button to turn on the back LED light; press repeatedly to switch color temperatures: White, Natural, and Warm. Continue short-pressing to turn off the back light.

Press and hold the button to dim or brighten the back light (10%–100%).