Tire Inflator

USER MANUAL



(Please read this manual before using this product)

WARNING

Children must not operate the Tire Inflator alone.
Never use the Tire Inflator in direct sunlight, high temperatures, or high pressure environments.
Keep the Tire Inflator away from water and rain; it is not suitable for use in water. To avoid damage, excess heat, toxic fumes, fire, or explosion, turn off and allow the Tire Inflator to cool for 30 minutes after 10 minutes of use.
Always turn off the power switch after use.
Before using this product, carefully read all warnings and instructions. Improper use can result in product damage beyond the Seller's responsibility.


ATTENTION


To minimize the risk of electric shock, avoid exposing your Tire Inflator to rain. It is
recommended to store it indoors and away from any sources of fire.
Attention:
1. This product may experience slight heating during normal operation, which is deemed a typical occurrence.
2. In order to prolong the air pump's lifespan, we do not recommend continuous inflation for more than 10 minutes. Should prolonged use be necessary,
intermittent breaks are advised to cool down your tire inflator.

PRODUCT PARAMETER

Product model	CZK-EB13A
Voltage	7.4 V
Power	60W

LAYOUT





1 Air hose
2 Digital display
3 Operation buttons
4 Air hose storage port
5 Type-C charging port
6 Light

Accessory:




Type-C cord x1




Multifunctional air nozzle

OPERATION GUIDE


Instructions for use
*Please charge it fully before use




Connect the end of the air hose to the tire valve.




Press and hold the "⏻" button to wake up the tire inflator.




Press and hold the "◌" button to switch unit.



Press the" ◌ " button to switch "🚗 🚙 🚲 🏍 ⚽ △" six modes.



Press "+" "-" button to preset tire pressure.



Press " ⏻ " to start the tire inflator.



The tire inflator will stop automatically once tire pressure reachespreset value.

SIX MODES



For Sedan Car Tire | For New energy vehicle Tire | For Motorcycle | For Bicycle | For Balls | Custom mode

PRESET TIRE PRESSURE

Press and hold "◌" to switch the unit. Use the "+" or "-" button to adjustthe numerical value, and wait a few seconds after setting for the numbers to stop flashing. Then turn on the inflation switch to start the process. The tire inflator will automatically stop inflating when it reaches the specified air pressure.

