


ST NEC

ASSEMBLY INSTRUCTIONS





IMPORTANT SAFETY INSTRUCTIONS



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

1. Safety Instructions

When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:

- This product must be assembled by an adult.
- Wearing gloves during assembly is highly recommended.
- Keep children and pets away while assembling the product.
- Do not let children climb on or play with the product.
- Always use the product on a firm, level ground.
- Do not use this product if any parts are missing, damaged, or worn.
- To avoid scratching the floor, assemble the product on a soft surface, such as a carpet.
- Do not over-tighten the fasteners.
- Regularly examine the product for wear and tear. Stop using the product at the first sign of damage or if parts become detached.
- Do not use power tools to assemble the product. Power tools may strip or damage the parts.
- Do not stand on the seat.
- Do not sit on the armrest.
- Keep all sharp objects away from the upholstery.
- Do not hang anything on the product.

2. Assembly

- For additional illustrated assembly steps, refer to the end of the written instructions.

3. Before First Use

- **Suffocation Hazard:** Packaging materials and small components such as screws, bolts, and other fasteners can pose a suffocation hazard. Always keep these parts out of reach of children and pets during assembly and ensure they are securely fastened to the product to prevent them from becoming loose over time.
- **Children's Safety:** Never leave children unattended with the chair. Teach children not to play with the chair, as it is not a toy. Climbing on the chair or playing with its moving parts can lead to falls or injuries. Additionally, ensure the chair is adjusted to a safe and appropriate height for children's use to prevent their feet from dangling, which can cause discomfort or pressure.
- **Pet Safety:** Be mindful of pets around your chair products. Pets, particularly those with a tendency to chew or claw, can damage the chair or even ingest small parts, leading to potential injury or health issues. Consider using protective covers or deterrents if your pets are known to chew on furniture.
- Remove all the packing materials.
- Review all components before assembly. Check the product for transport damages.




PRODUCT PRECAUTIONS

DO NOT STAND ON THE SEAT OR SIT ON THE ARMRESTS




Do not stand on the seat or sit on the armrests. The chair is not designed to support body weight in this manner and doing so may cause loss of balance or injury from falling.

DO NOT TILT THE CHAIR BACKWARD BEYOND ITS LIMIT




Do not lean back by lifting the front legs off the ground or forcing the backrest into a horizontal position. This may cause the chair to tip over and result in injury.


※Please make sure all the parts are included.




BACK X1



SEAT X1




ARMREST X2




CONTROL
MECHANISM X1




WHEEL X5




CENTRAL BASE X1



BASE LEG X5



GAS LIFT
CYLINDER X1



A X10
(SEAT + BACK
ARMREST)



B X4
(CONTROL
MECHANISM)



C X5
(BASE)





D X10
(WASHER)




E X1
(ALLEN KEY)

⚠ NOTICE

Do not tighten the bolts all the way before each bolt is in place per step.




Please use the **Allen key** included instead of an electric drill.



TIPS!

Use the box for an easier assembly.




Enjoy your new favorite chair

Our goal is to create a perfect customer experience.




• Instructions





※ Take off the base cover first


STEP 1 Bottom



1. Insert the base legs into the central base so that the bolt holes are aligned and facing up.






2. Secure with **bolts**.
Make sure to fully tighten all 5 bolts.



3. Insert each **wheel** into the **base leg** while the base is still upside down.


SAFETY CAUTION






- 4.** Turn the base over, and place the plastic cover back on the base.

STEP 2 Top




BACK BOLT


⚠ For proper alignment:
Slightly **under-tighten** the bolts.



- 6.** Line up the armrest and the back. Loosely tighten with two bolts. Repeat on the other side.




- 5.** Insert gas lift cylinder into the center of the base.




SEAT BOLT

WASHER




⚠ For proper alignment:
Slightly **under-tighten** the bolts.




- 7.** Put the armrests on the bottom of the seat and tighten with three bolts on each side.



- 8.** Once all of the armrest bolts are in place, **fully tighten** every bolt.




Order of bolts for better durability




- 9.** Align the control mechanism with the '**Front**' sticker and secure it to the seat.

STEP 3 Top + Bottom



- 10.** Mount the seat onto the gas lift cylinder.

Done!




• User Manual

Check

Right hand


Tension Adjustment

Tilt Tension




Clockwise: tighten tilt tension.
Counterclockwise: loosen tilt tension.

Tilt Lock



While backrest is upright: push lever in to lock tilt, pull out to enable tilt.

Height



**Enjoy your
new favorite chair.**

Our goal is to create a perfect customer experience.

• Care & Maintenance

Proper care and regular maintenance will help keep your chair clean and in good working condition.

CLEANING

- Clean regularly with a soft, dry or slightly damp cloth.
 - Wipe up spills promptly with a clean cloth.
 - Do not use abrasive cleaners, harsh chemicals, or excessive moisture.
 - Follow any care instructions specific to the materials used on your chair.
-

REGULAR MAINTENANCE

- Periodically check and tighten all screws, bolts, and connections.
 - Make sure the casters, base, and other components remain securely attached.
 - Check regularly for signs of wear, looseness, or damage.
 - Do not use the chair if any component is damaged or unstable.
-

CARE TIPS

- Use the chair on a stable, level surface.
- Avoid prolonged exposure to excessive heat, direct sunlight, or moisture.
- Do not drag the chair roughly across the floor.
- Use the chair only as intended and within the recommended weight capacity.