













# Assembly Instructions


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.(Note: Loosely thread all screws bolts first. Once the item is assembled then completely tighten.)

PARTS LIST:				HARDWARE LIST:			
NO.	DESCRIPTION	PART PHOTO	QTY	NO.	DESCRIPTION	PART PHOTO	QTY
A	TOP BOARD		1	D	ALLEN KEY ( $\varnothing \frac{4}{25}$ " )		1
				E	SCREW ( $M \frac{6}{25}$ "* $\frac{4}{5}$ " )		6
B	BOTTOM BOARD		1	F	WASHER ( $\varnothing \frac{16}{25}$ "- $\varnothing \frac{6}{25}$ "* $\frac{1}{25}$ " )		6
				G	SPRING SHIM ( $M \frac{6}{25}$ " )		6
C	SIDE FRAME		2	H	ALLEN KEY ( $\varnothing \frac{1}{5}$ " )		1
				I	SCREW ( $M \frac{8}{25}$ "* $1 \frac{1}{5}$ " )		4
				J	SPRING SHIM ( $M \frac{8}{25}$ " )		4
				K	WASHER ( $\varnothing \frac{18}{25}$ "- $\varnothing \frac{8}{25}$ "* $\frac{3}{50}$ " )		4

STEP 1



STEP 2



FINISH

