ITEM NO. NSHM0847

Scan for manual,
video & advice.

If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com

MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.
Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :
This brochure contains IMPORTANT safety info. Please read and keep it for future reference.

Weight Limitation
80 LBS


Installation:
45 minutes.


Two Person

Before You Start

Please follow the steps below:

- Unbox the package and check if all parts and accessories are complete.
- If you find something missing, stop assembly and contact your supplier immediately.
- Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
- NOTE:Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.

Warranty

We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having dificulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**

For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis,or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.

Exploded Diagram



Parts List

A x1



Top panel

B x1



Bottom panel

C x1



Left side panel

D x1



Right side panel

E x1



The middle link bar

F x1



Middle panel

G x1



Middle back panel

H x1



Baseplate

I x1



Back panel

J x2



Drawer back panel

K x2



Drawer left side panel

L x2



Drawer right side panel

M x2



Drawer bottom panel

N x2



Drawer front panel

O x4

Foots

Hardware List

1 x12+1

Screw
Ø3*14mm

2 x16+1

Flat washer

3 x16+1

Spring washer

4 x16+1

Flat head screw
Ø6*13mm

5 x23+2



Screw
Ø8*25mm

6 x2

Screw
Ø3*12mm

7 x4



Flat head screw
Ø6*25mm

8 x1



Socket

9 x1



Allen key

10 x1



Screwdriver

11 x4



Anti-tip
component

12 x4



Screw
Ø3.5*14mm

13 x4

screw
Ø3.5*35mm

14 x4



Wall anchor

15 x2

Tie

Assembly Instructions

Step 1

Insert part (G) into part (F),make sure all holes align ,connect part(F) to part (G) with screw(5), tight screw with screwdriver (10).

5	x 3	Ø8*25mm
10	x 1	screwdriver



Step 2

Insert panel (A) into panel (C),make sure all holes aligned and then tighten it with allen key (9) as picture show.

9	x 1	M4



Note:
The allen wrench must be keep at a 45 degree Angle to the panel A

Step 3

Insert panel (F&G) into panel (C),make sure all holes aligned and then tighten it with allen key (9) as picture show.

9	x 1	M4



Step 4

Insert panel (E) into panel (C),make sure all holes aligned and then tighten it with allen key (9) as picture show.

9	x 1	M4



Step 5

Insert side panel (D) into the corresponding hole of preassembled step (4) ,make sure all holes aligned and use allen key (9) to tightenit as picture show.

9	x 1	M4



Step 6

Connect panel (B) to panel (C/D)with bolt (7),tight bolt with allen key(9) .

7	x 4	Ø6*25mm
9	x 1	M4



Step 7

Insert back panel(I) into the groove of preassembled step (6),make sure all holes aligned and use screw#1 to attach them ， tighten screw (1) with screwdriver(10).

1	x 12	Ø3*14mm
10	x 1	screwdriver



Step 8

Insert gasket (3) and (2) in sequence into bolt (4), install leg (O)on of bottom panel (B), ensure the corresponding holes are aligned and fix with screw (4), then tighten the screw with an Allen key (9).

2	x 16	Flat washer
3	x 16	Spring washer
4	x 16	Ø6*13mm
9	x 1	M4



Step 9

Connect part (11) to top panel(A) with screw (12), tight screw withscrewdriver (16).

11	x 2	Anti-tip component
12	x 4	Ø3.5*14mm
10	x 1	screwdriver





Step 10

Insert part (H) into the preassembled step (9),make sure all holes aligned and use screw(5) to attach them,tighten screw (5) with screwdriver(10).

5	x 4	Ø8*25mm
10	x 1	screwdriver



Step 11

Insert part (8) into the preassembled step (10),make sure all holes aligned and use screw (6) to attach them,tighten screw (6) with screwdriver (10).

6	x 2	Ø3*12mm
8	x 1	Socket
10	x 1	screwdriver



Step 12



Attention:
Before the next step, adjust the feet of the locker to keep it level.







Step 13

1.Connect part (K&L) to part (N) using screw (5) and tighten it with screwdriver (10).
2.Slide in the part (M) into the groove in part (L&K). make sure they are also in groove in part (N).

5	x 8	Ø8*25mm
10	x 1	screwdriver



Step 14

Connect part (K&L) to part (J) using screw (5) and tighten it with screwdriver (10).

5	x 8	Ø8*25mm
10	x 1	screwdriver



Step 15

Attention：When installing the drawer,slide the steel ball slide rail of side panel to the most front as picture show.





Schematic diagram of slide rail disassembly



Step 16

Install Anti-tip device (11) to the wall in this step.

11	x 2	Anti-tip component
14	x 4	Wall anchor
13	x 4	Ø3.5*35mm
10	x 1	screwdriver





1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device (14) to the wall with screws (15)

Step 17

WARNING

Children have died from furniture tipover.
To reduce the risk of furniture tipover:
-ALWAYS install Anti-tip device provided.
-For use with televisions weighing 35 lb or less.Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
-NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
-NEVER open more than one drawer at a time.
-Place heaviest items in the lowest drawers.

Let the plastic belt (15) pass through the both part(11) and pull tightly.

15	x 2	Tie



WWW.HULALAHOME.COM
Email: customerservice@hulalahome.com
Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)