






ASSEMBLY INSTRUCTIONS

WF300935
N725P247766








Part List

			
①×2pcs	②×2pcs	③×5pcs	④×5pcs


Hardware List

 M6×25mm	 M6×30mm	 φ7X40mm	 D×8pcs	 M4
Ⓐ×40pcs	Ⓑ×10pcs	Ⓒ×25pcs	Ⓓ×8pcs	Ⓔ×1pc
 4x35mm	 Φ8x30mm	 Φ6x30mm	 Ⓢ×2pcs	
Ⓕ×2pcs	Ⓖ×10pcs	Ⓗ×2pcs	Ⓢ×2pcs	

Step 1



ⓓ × 8 pcs



Step 2




φ7X40mm

Ⓒ × 25 pcs



Φ8x30mm



Ⓔ × 10 pcs



X5


Step 3


M6×25mm
(A)×20pcs



Step 4


M6×25mm
(A)×20pcs




Step 5




M6×30mm

(B)×10pcs



Step 6



4x35mm

(F)×2pcs



Φ6x30mm

(H)×2pcs



(I)×2pcs

