


edishinē

**Tischlampe · Table Lamp · Lampe de table
Lampada da tavolo · Lámpara de mesa
Tafellamp · Lampa stołowa**

[Instruction Manual]



Please pay attention to the warning signs
Read the instructions with caution before operating
and keep it properly

V50718

Warning: To reduce the risk of fire, electric shock or personal injury, always follow the instructions strictly.

1. Before assembly, place all parts out on a clean flat surface and inspect each part for defects that may have occurred during shipping.
2. Inspect wire insulation for any cuts, abrasions or exposed copper that may have resulted during shipping. If there are any defects in the wire, DO NOT continue to assemble. Please send an email to our Customer Service immediately .
3. Consult a qualified electrician if you have any electrical questions.
4. Never drape clothes over the lamp.
5. To reduce the likelihood of tipping over, we recommend don't place the lamp at the edge of table and keep children and pets away.
6. To prevent children from suffocating and choking, keep them away from packing materials.
7. Please keep this manual and hand it over when you transfer the product.


Packing List



1



2



3




4



5

Part	Description	Quantity
1	Linen Shade	1
2	Socket Ring	1
3	Table Lamp	1
4	G45 Bulb	1
5	Instruction Manual	1

ASSEMBLY INSTRUCTIONS



1. Screw the first section of the light pole onto the base clockwise ① until it is tightened, Do the same for the second section of the light pole ②
2. Tighten the socket and lamp pole clockwise ③
3. Place the shade ④ on socket ⑤ then screw on the socket ring to fix the shade.
4. Screw the Bulb ⑥ clockwise onto Socket until tight.

Specifications

- Product Height: 38cm
- Base Diameter: 10cm
- Wire Length: 160cm
- Materials: Linen, Metal
- Input Voltage: 220-240Vac 50Hz
- Max.Load Power: Incandescent Bulb 60W or LED Bulb 12W
- Socket Type: Standard Medium E27

One Year Limited Warranty

Supported by our professional R&D team and QC team, we provide One Year Warranty for materials and workmanship from the purchase date. Please note that the warranty does not cover damage caused by personal misuse or improper installation.

Please attach your Order ID and Name so that our dedicated customer service team can help you better.



Disposing of the package

The package consists of cardboard and respectively labelled plastics that can be recycled.

Provide these materials for recycling.



Disposal of the product

This electrical appliance cannot be disposed of with domestic waste. Consumers are obligated to hand over electrical appliances to the manufacturer, the point of sale or a public collection point set up free of charge, based on resource conservation and environmental protection. Before the device is discharged, installed batteries or accumulators must be removed and disposed of separately.



Disposal of batteries and accumulators

Old batteries must not be disposed of with domestic waste, as they may contain harmful substances or heavy metals which may harm the environment. Waste batteries and accumulators must be disposed of in accordance with the prescribed regulations. Consumers are obliged to hand over batteries and accumulators free of charge to a public collection point set up for this purpose. Do not heat the batteries – Explosion hazard!

Cd Hg Pb



EU-Conformity

This product complies with conformity requirements of the applicable legislation.