
DGRT-V1

FTOFOD-6045/6049 FTOFOD-6046/6050 FTOFOD-6051/6052 FTOFOD-6053/6054



Notice:

- 1. Please unbox the item from the side with an open label and put a carpet on the floor to avoid scratching it.
- 2. Follow the installation instructions carefully. Before installation, please ensure that all accessories are present. For large items, we advise you to install them with 2 or more people for faster and safer installation.
- 3. Do not fully tighten the screws during initial assembly. Fully tighten the screws only once all pieces are correctly assembled. Do not use power tools.
- 4. Do not stand, climb, or swing on the product.
- 5. If you encounter any problems during installation, please contact our customer service.

Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
A	⊕	×64	B	Ø15*12mm	×56
C	€ 8*30mm	×18	D	мб*38mm	×42
E	5/32" ★12mm	×18	F	∭∭∭∭∭(⊕ 1 "*30mm	×4
G	Ø12*10mm	×8	H	$\frac{5}{32}"*20mm$	×3

Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
		×3	J	<(((C)) M3.5*14mm	×46
K		×1		M4	×1
M		×6	N	CL DL CR DR	×2
0		×2	P		×1
Q		×1	Screw driver needed But not included		

The hardware quantities listed above are required for proper assembly.


Some extra hardware may also have been included in the actual hardware bag.


Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
1		×1	2		×1
3		×1	4		×1
5		×1	6		×1
7		×1	8		×1
9		×1	10		×1


Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
		×1	12		×1
13		×1	14		×4
15		×1	16		×2
17		×1	18		×1
19		×1	20		×1


Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
21		×1	22		×1
23		×1	24		×1
25		×1	26		×1
27		×1	28		×1
29		×1	30		×1


Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
31		×1	32		×1
33		×2	34		×1
35		×1	36		×1
37		×1	38		×2
39		×1	40		×1



























































































































Please tear off the adhesive paper behind the light strip before pasting the light strip to parts#1




2 arrow marks must be on the same side before connecting










Please refer to hinge adjustment supplement next page

HINGE ADJUSTMENT SUPPLEMENT




In the event that the door does not align properly, the INSIDE Machine Screws located on the Hinges are for adjusting slightly to the Left or Right. **DO NOT LOOSEN THE OUTSIDE MACHINE SCREW FOR ADJUSTMENT.**

A. To adjust the door toward the OUTSIDE of the unit, turn the Inside Machine Screws to the LEFT, or COUNTERCLOCKWISE. (See Figure A)


B. To adjust the door toward the INSIDE of the unit, turn the Inside Machine Screws to the RIGHT, or CLOCKWISE. (See Figure B)

*Note: Please be patient, it may take several minutes to adjust properly.

Only once the door is in the desired position, fully tighten the OUTSIDE Machine Screws. This will ensure that the door is secure.



You may also need to adjust slightly the lower part of the door toward INSIDE of the unit at the same time.



You may also need to adjust slightly the lower part of the door toward OUTSIDE of the unit at the same time.

