




USER'S MANUAL





Parts List




Hardware List

A



1PC


B



1PC

C


M6x15mm



12PCS

D


M8x65mm



8PCS

E


M6x35mm



12PCS

F


M5x25mm



8PCS

G

ø8



8PCS

H

M8



4PCS

I

ø6




10PCS

J



M6




10PCS







1



2











M5x25mm

F 4PCS



M6x35mm

E 2PCS



A

