


# ASSEMBLY INSTRUCTIONS



- (1) Carefully remove all parts from box and remove all plastic covering from lamp parts.
- (2) Place the Lamp Base (A) on the floor.
- (3) Screw the Column (B) into the Lamp Base (A) while pulling cord through the base.
- (4) Screw the Column (C) into the Column (B) while pulling cord through the base.
- (5) Screw the Socket Assembly (D) into the Column (C) while pulling cord through the base.
- (6) Attach the Harp (E) on the Socket.
- (7) Place the Shade (F) on the Harp (E) and tighten it with the Finial (G).

**CAUTION:** TO REDUCE THE RISK OF FIRE USE 3-WAY 100 WATT

TYPE A  LAMP **MAX.**

## CAUTION: IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

**Made in China**

Dear Customer,

Congratulations on your purchase of this quality lamp. It has been produced under the highest quality standards. Please read carefully the following precautions before using this lamp:

- When unpacking and assembling, be careful not to pull wire with full strength, as an incorrect connection could result.
- Only use the bulb and wattage specified in this instructions or on the label located on the socket.
- Do not attempt to replace bulb while the lamp is plugged into an electrical outlet.
- Do not use outdoors, or near water or other liquids.
- Unplug from outlet before removal of any parts and cleaning.
- Only use soft cloth for cleaning. Do not use any chemical or abrasive cleaners.
- Remove the cellophane cover from shade before use.
- During shipment, the socket cover may have become loose. Before inserting bulb, check to see that the socket cover is in place.