







GB>ASSEMBLY INSTRUCTIONS

























Caution


GB>Please only clean with a duster or a damp cloth. Do no use any abrasive cleaners.

Dear customer, should there be any plece missing or damaged,kindly mark this piece clearly on the attached assembly instructions and return them to us.

Service Card


ACCESSORIES

 D	 G	 A	 B	 X	 S	 M	 H2	 F1	 KP	 X3
30	8	12	12	12	12	4	4	24	6	3
 I	 Z	 L	 GW	 H	 F	 RK	 KL	 ZB	 X3	 L10
10	4	4	20	8	4	6	2	1	8	4




WARIANT A

the front opens to the left







?







WARIANT B


front opens to the right









1 WARIANT B




2 WARIANT B








1 WARIANT A









2 WARIANT A




3



4



5



Z







Z

Z


G

F



7



6









x3




KL

KL


KL





KP





RP





A=B





7










8



9





10





A=B

11




12









GUIDELINES FOR FURNITURE USE AND MAINTENANCE

GB

1. Furniture should be used in rooms which are dry and protected against the harmful influences of weather conditions.
2. Furniture should be assembled in accordance with the assembly manual.
3. Furniture should be assembled as close as possible to its intended final location.
4. While positioning the furniture make sure it is levelled
5. Furniture may be moved only by lifting and carrying it over when emptied of its contents. Pushing it over or pulling it along may ruin the furniture permanently. While carrying the furniture over it must be held by its vertical elements, i.e. side panels or legs. Furniture cannot be held by its horizontal elements prone to destruction, i.e. desktops, drawer, etc..
6. Furniture should not be overloaded as this may ruin it permanently.
7. While using the furniture, the state of the connections between its elements should be checked if necessary.
8. Furniture surface must be cleaned only with furniture maintenance formulas.



GB>ASSEMBLY INSTRUCTIONS



Caution



GB>Please only clean with a duster or a damp cloth. Do no use any abrasive cleaners.





Dear customer, should there be any plece missing or damaged,kindly mark this piece clearly on the attached assembly instructions and return them to us.



Service Card

ACCESSORIES



8.0x30 D 20	4.0x27 G 4	 A 16	Ø15x12 B 16	 X 16	 X1 4	 O 4	 Q 1	 M 8	4.0x20 H2 8
 GW 10	 I 6	 L 4	"15" Z1 4	4.0x16 H 8	 F 2	 L10 8			









3






x2




B	H
16	16




4



F	Z1
2	4
G	H
4	8






5






D
4



6





7





8



9









GUIDELINES FOR FURNITURE USE AND MAINTENANCE

GB




1. Furniture should be used in rooms which are dry and protected against the harmful influences of weather conditions.
2. Furniture should be assembled in accordance with the assembly manual.
3. Furniture should be assembled as close as possible to its intended final location.
4. While positioning the furniture make sure it is levelled
5. Furniture may be moved only by lifting and carrying it over when emptied of its contents. Pushing it over or pulling it along may ruin the furniture permanently. While carrying the furniture over it must be held by its vertical elements, i.e. side panels or legs. Furniture cannot be held by its horizontal elements prone to destruction, i.e. desktops, drawer, etc..
6. Furniture should not be overloaded as this may ruin it permanently.
7. While using the furniture, the state of the connections between its elements should be checked if necessary.
8. Furniture surface must be cleaned only with furniture maintenance formulas.



GB>ASSEMBLY INSTRUCTIONS



Tools required narzędzia wymagane Werkzeuge erforderlich








Caution

GB>Please only clean with a duster or a damp cloth. Do no use any abrasive cleaners.


Dear customer, should there be any plece missing or damaged,kindly mark this piece clearly on the attached assembly instructions and return them to us.


Service card

ACCESORIES





				
Y	KR	O	Q	H2
2	2	5	1	4

x2













1









3



4



GB>ASSEMBLY INSTRUCTIONS
























Caution


GB>Please only clean with a duster or a damp cloth. Do no use any abrasive cleaners.



Dear customer, should there be any plece missing or damaged,kindly mark this piece clearly on the attached assembly instructions and return them to us.





Service card



ACCESSORIES

 D 40	 G 12	 A 8	 B 8	 X 8	 S1 8	 M 6	 H2 6	 X3 8	 F 32	 KL 3
 I 18	 Z 4	 L 4	 PR 2	 H 8	 F 6	 L10 6	 MS 1	 O 8	 Q 1	














3




4





5





6









x4




7






 F 2	 Z 4
 G 4	 H 8





8




 Q 1	 O 8
---	---



9







10






	X3
2	

	I
6	




A=B


11




1





2

















3



4



12



GUIDELINES FOR FURNITURE USE AND MAINTENANCE

GB

1. Furniture should be used in rooms which are dry and protected against the harmful influences of weather conditions.
2. Furniture should be assembled in accordance with the assembly manual.
3. Furniture should be assembled as close as possible to its intended final location.
4. While positioning the furniture make sure it is levelled
5. Furniture may be moved only by lifting and carrying it over when emptied of its contents. Pushing it over or pulling it along may ruin the furniture permanently. While carrying the furniture over it must be held by its vertical elements, i.e. side panels or legs. Furniture cannot be held by its horizontal elements prone to destruction, i.e. desktops, drawer, etc..
6. Furniture should not be overloaded as this may ruin it permanently.
7. While using the furniture, the state of the connections between its elements should be checked if necessary.
8. Furniture surface must be cleaned only with furniture maintenance formulas.

