



TOOLS REQUIRED



Screwdriver
(Not included)



2 - People

ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

ARMLESS CHAIR




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1



Back Cushion
1 pc.

2



Seat Cushion
1 pc.

ASSEMBLY INSTRUCTIONS

CAUTION: PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING ASSEMBLY PROCESS. IT IS RECOMMENDEDTO USE TWO PEOPLE WHEN ASSEMBLING AND REMOVING THE INSIDE BACKS TO AND FROM THE BASE OF THE FURNITURE.

Once the box has been removed from around the chair, you'll notice the back is laying on top of the seat. There are a couple items to remove from the seat portion of the chair first. Follow the steps below:

1 **Attach the Back (1) to the Seat (2). Ensure the latches fit well. (See Figure 1.1)**




Figure 1.1

2 **You can connect two or more recliners by connecting each position with male and female buckle as Figure 2.2 illustrated. (See Figure 2.2)**




Figure 2.2

ASSEMBLY INSTRUCTIONS

3 Connecting power cords with each position. (See Figure 3.1)




Figure 3.1

4 Fasten the back flap to the bottom of the furniture. (See Figure 4.1)




Figure 4.1

ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. if the product wobbles or feels loose.double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manualand any order-related information for future reference.

Lift, don't drag!

To avoid damage to praduct please always LIFT the product when transporling ol adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.


[redacted]

MODEL #

Questions?

GIVE US A CALL: 1-888-980-5122
MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED



Screwdriver
(Not included)



2 - People

ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE


FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

ARMLESS RECLINER






- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.


PARTS

1



Back Cushion
1 pc.

2



Seat Cushion
1 pc.

ASSEMBLY INSTRUCTIONS

CAUTION: PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING ASSEMBLY PROCESS. IT IS RECOMMENDEDTO USE TWO PEOPLE WHEN ASSEMBLING AND REMOVING THE INSIDE BACKS TO AND FROM THE BASE OF THE FURNITURE.

Once the box has been removed from around the chair, you'll notice the back is laying on top of the seat. There are a couple items to remove from the seat portion of the chair first. Follow the steps below:

1

1 **Attach the Back (1) to the Seat (2). Ensure the latches fit well. (See Figure 1.1)**




Figure 1.1

ASSEMBLY INSTRUCTIONS

2 **Zip up the seat cushion and back cushion.**
(See Figure 2.1)





Figure 2.1

ASSEMBLY INSTRUCTIONS

3 **Flip up the back flap and remove the cables from the Backs (1). Plug all the connecters.**
(See Figure 3.1)



THE HEADREST LEADWIRES IS YELLOW.
THE LUMBAR LEADWIRES IS GREY.

Figure 3.1

ASSEMBLY INSTRUCTIONS

4 **You can connect two or more recliners by connecting each position with male and female buckle as Figure 4.1 illustrated.**
(See Figure 4.1)




Figure 4.1

ASSEMBLY INSTRUCTIONS

5 **Connecting power cords with each position.**
(See Figure 5.1)




Figure 5.1

ASSEMBLY INSTRUCTIONS

6 **Fasten the back flap to the bottom of the furniture. (See Figure 6.1)**




Figure 6.1

ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. if the product wobbles or feels loose.double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!
Please retain this instruction manualand any order-related information for future reference.

Lift, don't drag!
To avoid damage to praduct please always LIFT the product when transporling ol adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

Disassembly Instructions

To remove the back from the base, use a screwdriver pressing outward on the black tab in the metal receivers on both sides of the chair back and lift the back from the base of the chair to release. (See Figure 9.1)

SCREWDRIVER REQUIRED
(NOT INCLUDED)





Figure 7.1

OPERATING INSTRUCTIONS

CAUTION: READ THE IMPORTANT INSTRUCTIONS BELOW BEFORE OPERATING YOUR POWER MECHANIZED EQUIPMENT

Do not allow children to play on or operate this power mechanized equipment



Care should always be taken to assure there is nothing in the path of the mechanism before and during operation.

To recline: Sit on the furniture, and press the front of the button closest to the footrest to smoothly raise the footrest and recline to any position. To lower the footrest and return to an upright position, press the back side of the button closest to the footrest.

To adjust headrest: Press the front of the button closest to the backrest to smoothly raise and adjust the headrest to any position. To lower the headrest and return it to its original position, press the back side of the button closest to the backrest.

To adjust lumbar support: Press the front of the center button to smoothly raise and adjust the lumbar support to any position. To lower the lumbar support and return it to its original position, press the back side of the center button.

To close all: To simultaneously return the headrest, footrest, and lumbar support to their original positions, press and hold the back side of the button closest to the footrest.

TROUBLE SHOOTING

PROBLEM	POSSIBLE FACTORS	SOLUTIONS
Chair doesn't recline	Transformer may not be connected well	• Check that the power supply has been correctly connected to transformer and socket • Confirm the wire from chair to transformer is firmly connected
Recliner power not working	Power outlet on wall not functioning	• Check power from your wall outlet • Plug in a different device to make sure outlet has power
Headrest or lumbar doesn't work*	Headrest or lumbar motor wires may not be properly connected inside back flap of chair	• Check that the headrest (yellow) and lumbar (grey) motor wires have been correctly connected ***Connecting the wires to their correct color is extremely important***
Headrest and lumbar doesn't work*	Headrest and lumbar motor plug have been cross connected	• Check that the headrest (yellow) and lumbar (grey) motor wires have been correctly connected ***Connecting the wires to their correct color is extremely important***


[redacted]


MODEL #

Questions?

GIVE US A CALL: 1-888-980-5122
MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED





Screwdriver
(Not included)



2 - People

ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

WEDGE




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1




Left Back Cushion
1 pc.

2



Right Back Cushion
1 pc.

3



Seat Cushion
1 pc.

ASSEMBLY INSTRUCTIONS

CAUTION: PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING ASSEMBLY PROCESS. IT IS RECOMMENDEDTO USE TWO PEOPLE WHEN ASSEMBLING AND REMOVING THE INSIDE BACKS TO AND FROM THE BASE OF THE FURNITURE.

Once the box has been removed from around the chair, you'll notice the back is laying on top of the seat. There are a couple items to remove from the seat portion of the chair first. Follow the steps below:

1 **Attach the Backs (1) and (2) to the Seat (3). Ensure the latches fit well. (See Figure 1.1)**
Notice: You can distinguish the left wedge back and right wedge back by the zipper in the wedge backs as pictured illustrated.




Figure 1.1

2 **You can connect two or more recliners by connecting each position with male and female buckle as Figure 2.2 illustrated. (See Figure 2.2)**




Figure 2.2

ASSEMBLY INSTRUCTIONS

3 **Fasten the back flaps to the bottom of the furniture. (See Figure 3.1)**




Figure 3.1

Disassembly Instructions

To remove the back from the base, use a screwdriver pressing outward on the black tab in the metal receivers on both sides of the chair back and lift the back from the base of the chair to release. (See Figure 4.1)

SCREWDRIVER REQUIRED (NOT INCLUDED)




Figure 4.1

ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. if the product wobbles or feels loose.double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!
Please retain this instruction manualand any order-related information for future reference.

Lift, don't drag!
To avoid damage to praduct please always LIFT the product when transporling ol adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.


[redacted]


MODEL #

Questions?

GIVE US A CALL: 1-888-980-5122
MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED





Screwdriver
(Not included)



2 - People

ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CONSOLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1



Back Cushion
2 pc.

2



Seat Cushion
1 pc.

ASSEMBLY INSTRUCTIONS

CAUTION: PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING ASSEMBLY PROCESS. IT IS RECOMMENDEDTO USE TWO PEOPLE WHEN ASSEMBLING AND REMOVING THE INSIDE BACKS TO AND FROM THE BASE OF THE FURNITURE.

Once the box has been removed from around the chair, you'll notice the back is laying on top of the seat. There are a couple items to remove from the seat portion of the chair first. Follow the steps below:

1 **Attach the Back (1) to the Seat (2). Ensure the latches fit well. (See Figure 1.1)**




Figure 1.1




Figure 2.1

2 **You can connect two or more recliners by connecting each position with male and female buckle as Figure 2.1 illustrated. (See Figure 2.1)**

3 **Connecting power cords with each position. (See Figure 3.1)**




Figure 3.1

ASSEMBLY INSTRUCTIONS

4 **Fasten the back flap to the bottom of the furniture. (See Figure 4.1)**




Figure 4.1




Figure 5.1

ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. if the product wobbles or feels loose.double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manualand any order-related information for future reference.


Lift, don't drag!

To avoid damage to praduct please always LIFT the product when transporling ol adjusting the placement.

Disassembly Instructions

To remove the back from the seat, just pull the back out.(See Figure 5.1)

OPERATING INSTRUCTIONS




This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

User Wireless Charging Guidelines




ATTENTION – WIRELESS CHARGING

1. **Heat During Charging:** Some heat may be generated during wireless charging. This is normal during the wireless energy transfer process.
2. **Proper Placement:** Center the phone on the wireless charging icon or charging area for proper alignment and efficient charging.
3. **Keep the Charging Area Clear:** Remove coins, keys, cards, metal objects, and other foreign materials from the charging area before use. Foreign objects may interfere with charging or cause excessive heat.
4. **Avoid Metal Components:** Do not charge a device with a case or accessory containing metal components, as they may interfere with charging and become hot.
5. **Phone Cases:** Thick or incompatible phone cases may reduce charging performance and increase heat. Remove the case if the device does not charge properly.
6. **Excessive Heat:** If the phone or charging surface becomes excessively hot, stop charging and allow it to cool before resuming use.



TOOLS REQUIRED



Screwdriver
(Not included)



2 - People

ASSEMBLY RATING



EASY ⟶ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

LEFT RECLINER




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1



Back Cushion
1 pc.

2



Seat Cushion
1 pc.

3



Wing
1 pc.

HARDWARE

A



Transformer
1 pc.

ASSEMBLY INSTRUCTIONS

CAUTION: PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING ASSEMBLY PROCESS. IT IS RECOMMENDEDTO USE TWO PEOPLE WHEN ASSEMBLING AND REMOVING THE INSIDE BACKS TO AND FROM THE BASE OF THE FURNITURE.

Once the box has been removed from around the chair, you'll notice the back is laying on top of the seat. There are a couple items to remove from the seat portion of the chair first. Follow the steps below:

1 **Detach the transformer from the back rail of the mech under the seat (2). (See Figure 1.1)**




Figure 1.1

ASSEMBLY INSTRUCTIONS

2 **Attach the Back (1) to the Seat (2). Ensure the latches fit well. (See Figure 2.2)**




Figure 2.2

ASSEMBLY INSTRUCTIONS

3 **Zip up the seat cushion and back cushion.**
(See Figure 3.1)





Figure 3.1

4 **Flip up the back flap and remove the cables from the Backs (1). Plug all the connecters.**
(See Figure 4.1)



THE HEADREST LEADWIRES IS YELLOW.
THE LUMBAR LEADWIRES IS GREY.

Figure 4.1

ASSEMBLY INSTRUCTIONS

5 **You can connect two or more recliners by connecting each position with male and female buckle as Figure 5.1 illustrated.**
(See Figure 5.1)




Figure 5.1

ASSEMBLY INSTRUCTIONS

6 **Connecting power cords with each position.**
(See Figure 6.1)




Figure 6.1

ASSEMBLY INSTRUCTIONS

7 **Plug the end cord of transformer into the recliner, Then plug the transformer into a nearby outlet. Make sure the cord doesn't touch the mechanism. (See Figure 7.1)**




Figure 7.1

8 **Fasten the back flap to the bottom of the furniture. (See Figure 8.1)**




Figure 8.1



This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

Disassembly Instructions

To remove the back from the base, use a screwdriver pressing outward on the black tab in the metal receivers on both sides of the chair back and lift the back from the base of the chair to release. (See Figure 9.1)





Figure 9.1

OPERATING INSTRUCTIONS

CAUTION: READ THE IMPORTANT INSTRUCTIONS BELOW BEFORE OPERATING YOUR POWER MECHANIZED EQUIPMENT

Do not allow children to play on or operate this power mechanized equipment



Care should always be taken to assure there is nothing in the path of the mechanism before and during operation.

To recline: Sit on the furniture, and press the front of the button closest to the footrest to smoothly raise the footrest and recline to any position. To lower the footrest and return to an upright position, press the back side of the button closest to the footrest.

To adjust headrest: Press the front of the button closest to the backrest to smoothly raise and adjust the headrest to any position. To lower the headrest and return it to its original position, press the back side of the button closest to the backrest.

To adjust lumbar support: Press the front of the center button to smoothly raise and adjust the lumbar support to any position. To lower the lumbar support and return it to its original position, press the back side of the center button.

To close all: To simultaneously return the headrest, footrest, and lumbar support to their original positions, press and hold the back side of the button closest to the footrest.

TROUBLE SHOOTING

PROBLEM	POSSIBLE FACTORS	SOLUTIONS
Chair doesn't recline	Transformer may not be connected well	• Check that the power supply has been correctly connected to transformer and socket • Confirm the wire from chair to transformer is firmly connected
Recliner power not working	Power outlet on wall not functioning	• Check power from your wall outlet • Plug in a different device to make sure outlet has power
Headrest or lumbar doesn't work*	Headrest or lumbar motor wires may not be properly connected inside back flap of chair	• Check that the headrest (yellow) and lumbar (grey) motor wires have been correctly connected ***Connecting the wires to their correct color is extremely important***
Headrest and lumbar doesn't work*	Headrest and lumbar motor plug have been cross connected	• Check that the headrest (yellow) and lumbar (grey) motor wires have been correctly connected ***Connecting the wires to their correct color is extremely important***

FCC INSTRUCTION

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


[redacted]


MODEL #

Questions?

GIVE US A CALL: 1-888-980-5122
MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED





Screwdriver
(Not included)



2 - People

ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

RIGHT POWER RECLINER




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

1



Back Cushion
1 pc.

2



Seat Cushion
1 pc.

3



Wing
2 pc.

HARDWARE

A



Transformer
1 pc.

ASSEMBLY INSTRUCTIONS

CAUTION: PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING ASSEMBLY PROCESS. IT IS RECOMMENDEDTO USE TWO PEOPLE WHEN ASSEMBLING AND REMOVING THE INSIDE BACKS TO AND FROM THE BASE OF THE FURNITURE.

Once the box has been removed from around the chair, you'll notice the back is laying on top of the seat. There are a couple items to remove from the seat portion of the chair first. Follow the steps below:

1 **Detach the transformer from the back rail of the mech under the seat (2). (See Figure 1.1)**




Figure 1.1

ASSEMBLY INSTRUCTIONS

2 **Attach the Back (1) to the Seat (2). Ensure the latches fit well. (See Figure 2.2)**




Figure 2.2

ASSEMBLY INSTRUCTIONS

3 **Zip up the seat cushion and back cushion.**
(See Figure 3.1)





Figure 3.1

4 **Flip up the back flap and remove the cables from the Backs (1). Plug all the connecters.**
(See Figure 4.1)



THE HEADREST LEADWIRES IS YELLOW.
THE LUMBAR LEADWIRES IS GREY.

Figure 4.1

ASSEMBLY INSTRUCTIONS

5 **You can connect two or more recliners by connecting each position with male and female buckle as Figure 5.1 illustrated.**
(See Figure 5.1)




Figure 5.1

ASSEMBLY INSTRUCTIONS

6 **Connecting power cords with each position.**
(See Figure 6.1)




Figure 6.1

ASSEMBLY INSTRUCTIONS

7 **Plug the end cord of transformer into the recliner, Then plug the transformer into a nearby outlet. Make sure the cord doesn't touch the mechanism. (See Figure 7.1)**




Figure 7.1

8 **Fasten the back flap to the bottom of the furniture. (See Figure 8.1)**




Figure 8.1



This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

Disassembly Instructions

To remove the back from the base, use a screwdriver pressing outward on the black tab in the metal receivers on both sides of the chair back and lift the back from the base of the chair to release. (See Figure 9.1)





Figure 9.1

OPERATING INSTRUCTIONS

CAUTION: READ THE IMPORTANT INSTRUCTIONS BELOW BEFORE OPERATING YOUR POWER MECHANIZED EQUIPMENT

Do not allow children to play on or operate this power mechanized equipment



Care should always be taken to assure there is nothing in the path of the mechanism before and during operation.

To recline: Sit on the furniture, and press the front of the button closest to the footrest to smoothly raise the footrest and recline to any position. To lower the footrest and return to an upright position, press the back side of the button closest to the footrest.

To adjust headrest: Press the front of the button closest to the backrest to smoothly raise and adjust the headrest to any position. To lower the headrest and return it to its original position, press the back side of the button closest to the backrest.

To adjust lumbar support: Press the front of the center button to smoothly raise and adjust the lumbar support to any position. To lower the lumbar support and return it to its original position, press the back side of the center button.

To close all: To simultaneously return the headrest, footrest, and lumbar support to their original positions, press and hold the back side of the button closest to the footrest.

TROUBLE SHOOTING

PROBLEM	POSSIBLE FACTORS	SOLUTIONS
Chair doesn't recline	Transformer may not be connected well	• Check that the power supply has been correctly connected to transformer and socket • Confirm the wire from chair to transformer is firmly connected
Recliner power not working	Power outlet on wall not functioning	• Check power from your wall outlet • Plug in a different device to make sure outlet has power
Headrest or lumbar doesn't work*	Headrest or lumbar motor wires may not be properly connected inside back flap of chair	• Check that the headrest (yellow) and lumbar (grey) motor wires have been correctly connected ***Connecting the wires to their correct color is extremely important***
Headrest and lumbar doesn't work*	Headrest and lumbar motor plug have been cross connected	• Check that the headrest (yellow) and lumbar (grey) motor wires have been correctly connected ***Connecting the wires to their correct color is extremely important***

FCC INSTRUCTION

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.