

**Remote control priority function**  
**Please refer to the use of the remote control description.**  
**The remote control must be used under the adults' supervision.**



**Suitable age: For children between 36 months to 95 months old only.**  
**(please use this vehicle under the supervision of adults.)**

**⚠ Warning!**

For Safety sake:

- \*Please use this vehicle under the adults guidance and supervision.
- \*Prohibited to use this product on the road, slopes, highway or other dangerous places.
- \*When driving, children must wear shoes and helmet.
- \*When driving, children should be seating in the seat and fasten the seat belt.
- \*The maximum loading capacity of this vehicle is 50kgs/110lbs
- The users must be aged 36 months to 95 months.



**FREDDO**

**RAIDER**

SKU#:FR9012

## CHILDREN BATTERY CAR SPECIFICATIONS

### Installation and operating instructions

Applicable age: 36 months to 95 months

Execution standard: GB6675.1-2014,GB6675-2-2014,GB6675-3-2014,GB6675.4-2014

GB19865-2005

EN71/EN62115/EMC/ASTM-F963


Ⓜ2.4G remote control. Remote control can control forward,backward,right and left turn.

The remote control must be used under the adults supervision.

ⓂThe steering wheel has music player functions.

ⓂEquipped with safe belt,anti-vibration function.


ⓂSwing function (if requested)



**Please use the vehicle under the supervision of adults.**  
**Not suitable for children under 36 months**

## Thank you for choosing this children battery car.

Please read through this instruction before using this product. It will show you the correct method of installation and operation. In order to avoid the incorrect method causing the damage of the product or hurting your baby, please keep this instruction properly.



## Troubleshooting


■ Problem: the vehicle can not move

Answer 1: it is low battery

Please charge in time after each use, charge at least once each month. Recommend to charge 4 to 6 hours but not more than 10 hours.

Answer 2: overloading

An automatic reset fuse is equipped in the battery box. When overloading, it will cut off the power for 15 to 20 seconds, then restart.



To avoid fuse cut off the power:

- 1.Max:50kgs/110lbs, overbad is forbidden.
- 2.Do not drag any items behind this products.
- 3.Do not allow water or other liquids dip the electrical parts.
- 4.Do not change the line system by yourself.

Answer3: battery is broken

Please contact the agent or manufacturer.

Answer4:car body wiring has been damaged

Please contact the agent or manufacturer.

Answer5:the motor is damaged

Please contact the agent or manufacturer.

■ Problem: unable to charge

Answer1: the battery plug-ins loose

Make sure the battery terminals have connected with the wires tightly.

Answer2: the charger is not inserted in place

Make sure the charger is plugged into the power outlet properly(ensure the power outlet switch turn on)

Answer3: the charger can not work normally

If the charger doesnot work, please contact the agent or manufacturer.

■ Problem: vehicle run for a short time

Answer 1: the battery is not fully charged

The charging time is not enough, please charge in time after each use.

Recommend to charge 8 to 12 hours but not exceeding 20 hours.

Answer2: battery using age

Battery service life:1-3 years, otherwise, change a new one.

■ Problem: charger makes a buzzing sound while charging

This is normal.

■ Problem: charger heating phenomenon

This is normal. If the battery temperature is too high, please check either the current flow is too strong or battery internal short-circuit.

## Note on Safety

1. This vehicle is not suitable for children under 36 months. Please use this vehicle under the supervision of adults.
2. Please keep this vehicle far from pool, highway, slopes or other dangerous places.
3. To avoid gearbox and motor damage, ensure the vehicle has completely stopped when shift gears.
4. Before using, adults should check the main parts:battery, charger, wires, plugs, security risks. Any damage found, stop using until well repaired.
5. To avoid rust lubricate the iron parts with lubricating oil after using for some time.
6. The vehicle should be kept away from fire and long-term light side-up for shortage, upside down.
7. Do not use the fuse not matching the product.
8. Do not change the wire system by yourself, the repair work must be carried out under the guidance of professionals and technical staff.

### Warning!

- \*For the remote control function, please take reference to the instruction in the remote control box.
- \*To avoid gearbox and motor damage, ensure the vehicle has completely stopped when shift gears.
- \* Running function: Set in the switch in forward state, the vehicle will move forward when you stepping on "foot pedal". Set it in backward state, the vehicle will move backward. Set the switch in the middle state, the vehicle can not move. (If the car has remote control function, you can also control the car with the remote control.)

### Charging Warning!



#### Warning!

To avoid fires and electric shock:

- Only allowed to use the battery and charger prescribed by the manufacturer. Prohibite to use the other brand.
- Do not put the battery and charge in other products.
- It is not allowed to change the line structure privately.
- Do not link positive terminal and negative terminal by any conductor.
- Please keep the battery dry, far away from any liquid.
- When charging, do not smoking nearby, any flames may cause explosion.
- Please charge the vehicle in well ventilated, dry area.

#### Charging precautions

- \* Battery can not be reversed.
- \* Battery type: closed dry battery.
- \* Please check the charger, battery and plug before charging. If any damage found, stop using unless repair intact.
- \* It's normal for battery heating in charging process. If the temperature in too high, please check either the current flow is too strong or battery internal short-circuit.
- \* To avoid likely damage caused by battery to child, must fix the battery with platen.
- \* If the vehicle unused for long time, it must be fully charged, and charge once each month to ensure the battery life.
- \* Batteries are only to be charged by adults or children at least 8 years old.
- \* The batteries of the remote control are non-rechargeable, do not charge them.
- \* Batteries should be installed with the correct polarity. Do not mixed different types of batteries or new and used batteries. Exhausted batteries must be removed from the vehicles.

When charging, turn off the power switch.


After first use, recommend to charge 16 hours but not more than 20 hours.

When the vehicle speed slows down obviously, indicating the battery is low, please charge.


After use, please charge 8 to 12 hours, not exceeding 20 hours.

### 1. The damper installation


Turn over the car body, put the two dampers into the two damper holes on the two sides. same as the picture below.



## 2. Wheels installation



## Dash-board Function




### Player instruction

|                           |                  |                           |                 |            |                                                                            |
|---------------------------|------------------|---------------------------|-----------------|------------|----------------------------------------------------------------------------|
| VOL-                      | short time press | switch to the formal song | long time press | voice down | when open the power of the car, press two times, play the SD music         |
| SCAN                      | short time press | pause/play                |                 |            |                                                                            |
| VOL+                      | short time press | switch to the next song   | long time press | voice up   | when open the power of the car, press two times, play the main board music |
| MODE                      | short time press | switch function           |                 |            |                                                                            |
| oneside music button      | short time press | horn                      | long time press | voice down | press the horn sound, music stops                                          |
| another side music button | short time press | switch to the next song   | long time press | voice up   |                                                                            |


### 7.Spare wheel installation.

Lock the backrest and black plastic part with two 4\*14 screws in the correct holes(see picture).Insert the spare wheel to the car body ,settle it with the correct hole.




### 3.Power connection

Open the car hood, take off the power protection cover ,Connect the power terminal port with the main line. red line connects with red line(note: connect the pole in correct way)




#### 4. Car seat installation

Insert the backrest on the car body, then insert the car seat on the backrest. Insert the two hooks into the two holes on the car body, lock it with two 4\*14 screws.



#### 5. Steering wheel installation

Connect the lines, put the lines into the steering wheel hole. Unlock the steering wheel screw, pull up the steering wheel axle, insert the steering wheel to the axle, lock it with the screw.



#### 6. Front handlebar, windshield and back plastic parts ( 3 pieces ) installation.

Insert the front handlebar into the car body, settle it with the holes. Same installation for windshield and back plastic parts (3 pieces)

