



TV Stand 53.14


INCLUDED IN THE PACKAGE



REAR VIEW






FRONT VIEW
















n.° ID	Parts Identification (Description)	Quantity
01	Base	1
02	Top Panel	1
03	Left Side Panel	1
04	Left Partition	1
05	Shelf	2
06	Right Partition	1
07	Right Side Panel	1
08	Door	1
09	Left and Right Back Panel	2
10	Lower Middle Back Panel	1
11	Upper Middle Back Panel	1
12	Wood Feet	4


TOOLS NEEDED

 	
--	---

INCLUDED IN THE PACKAGE

A 4x 	B 4x 	C 24x 
D 13x 	E 7x 	F 7x 
G 13x 	H 11x 	I 50x 
J 2x 	K 8x 	L 4x 
M 1x 		


STEP 1



Preparing the door:


- Insert the plastic ring (M) in the Door (08).
- Fix the hinges (J) in the Door (08) with bolts (K), as shown in DETAIL 1.

STEP 2




- Fix the feet (12) under the Base (01) with bolts (A).
- Apply the protective felt covers (L) on the bottom of the feet (12).
- Apply the plastic covers (B) on top of the bolts (A).

STEP 3




- Connect Shelves (05) into Partitions (04) and (06) with dowels (C) and bolts (D).

STEP 4



- Connect Side Panels (03) and (07) into the Base (01) with dowels (C) and bolts (D).
- Connect Partition Parts (04) and (06) into the Base (01) with dowels (C) and bolts (D).


STEP 5



- Connect the Top Panel (02) onto Side Panels and Partitions (03), (04), (06) and (07) using dowels (C) and the Minifix hardware (E + F).
- Apply adhesive covers (G) on the minifix hardware (F).


DETAIL 2

STEP 6



- Connect Back Panels (09), (10) and (11,) with nails (I).
- Use metallic plates (H) and nails (I) at the joining surfaces.

STEP 7



Installing the door (08):

- Fix the hinge connectors (J) of the Door (08) on the Right Side Panel (07) with bolts 3.5 x 14mm (K), taking the markings on the panel (07) as reference for correct positioning. The hinge connector includes two bolts, shown in DETAIL 3. Use the fixer bolt and the adjustment bolt to tighten, adjust and align the door.

DETAIL 3