




GAMING DESK

user manual



CONTENTS

1 PRE-INSTALLATION PREPARATION..... 01

1-1 THANK YOU FOR CHOOSING OUR PRODUCT	01
1-2 PACKAGE CONTENTS	01
1-3 PRECAUTIONS	01

2 INSTALLING MODULES..... 02

2-1 DISASSEMBLY DIAGRAM	02
2-2 PARTS LIST	03
2-3 ASSEMBLY INSTRUCTIONS	05

3 CUSTOMER SERVICE..... 16

3-1 30-DAY RETURN POLICY	16
3-2 1-YEAR WARRANTY	16
3-3 QUICK RESPONSE WITHIN 24 HOURS	16

4 PROBLEMS YOU MAY ENCOUNTER 17

THANK YOU FOR CHOOSING OUR PRODUCT.

Before assembly, please read this USER MANUAL first, and check according to Parts List to make sure all parts are included.

Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority!


PACKAGE CONTENTS

Gaming Desk	Assembly Tool Kit	Instruction Manual
-------------	-------------------	--------------------

PRECAUTIONS



Avoid long-term direct sunlight exposure.



Keep away from heat.



Keep away from sharp objects.



Keep infants/children away from assembly parts to avoid choking and suffocation.




Keep away from corrosive substances.


















Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.

DISASSEMBLY DIAGRAM









For ease and safety, we recommend two people for assembly.




PARTS LIST

<div>A</div> <div>x1</div> <div></div>	<div>B</div> <div>x1</div> <div></div>	<div>C</div> <div>x2</div> <div></div>	<div>D</div> <div>x1</div> <div></div>			
<div>E</div> <div>x1</div> <div></div>	<div>F</div> <div>x1</div> <div></div>	<div>G</div> <div>x1</div> <div></div>	<div>H</div> <div>x2</div> <div></div>			
<div>K</div> <div>x1</div> <div></div>	<div>L</div> <div>x1</div> <div></div>	<div>M</div> <div>x1</div> <div></div>				
<div>1</div> <div>x5</div> <div></div>	<div>2</div> <div>x6</div> <div></div>	<div>3</div> <div>x24</div> <div></div>	<div>4</div> <div>x5</div> <div></div>			
1Spares	M6x12	1 Spares	M6x30	3 Spares	ST4x12	1 Spares

PARTS LIST



<div> <div>5</div> <div>x3</div>  <div>1 Spares</div> </div>	<div> <div>6</div> <div>x5</div>  <div>1 Spares</div> </div>	<div> <div>7</div> <div>x1</div>  </div>	<div> <div>8</div> <div>x1</div>  </div>
<div> <div>9</div> <div>x1</div>  </div>	<div> <div>10</div> <div>x1</div>  </div>	<div> <div>11</div> <div>x2</div>  <div>1 Spares</div> </div>	<div> <div>12</div> <div>x1</div>  </div>



ASSEMBLY INSTRUCTIONS

1



Install the feet ①.



2

In this step, the screws must only be 70% tightened: Use screws ③ to mount E, F, and G between parts C.

Please note: The holes on parts F and G (as shown in the figure) must face the same side.






ASSEMBLY INSTRUCTIONS

3

Use screws ③ to install D between E and F.




Please note: Tighten all screws (including the screws in the previous step) to 100% tightness after aligning the holes.


D x1	
③ x2	
11 x1	



ASSEMBLY INSTRUCTIONS

- 4** Install the desk leg on the desk board A with screws ③. Please determine the direction of desk board A and the desk leg when installing according to the arrows in the picture.

A x1	
③ x8	
⑪ x1	




ASSEMBLY INSTRUCTIONS

5


Install the desk board B with screws ③.

Please note: The screws must only be 70% tightened.




ASSEMBLY INSTRUCTIONS

- 6** Choose the LED strip ⑨ output line placed left or right according to your preference, and ensure the controller and the wire of the LED strip are located on the same side.



PLEASE NOTE:

With the back side facing table board A and the lighting side facing table board B (important), place the LED strip ⑨ vertically into the gap and keep the end of the light strip ⑨ flush with the edge of the table, then tighten the previous step screws to 100% tightness after aligning the holes.




ASSEMBLY INSTRUCTIONS

- 7** If the led strip ⑨ is not aligned or needs to adjust the position, please loosen the fixing screws ③ on part B, gently lift the strip side and pull it out from the desk gap side horizontally to re-install it.

PLEASE NOTE:


Please do not lift the strip side with force to cause excessive bending of the strip, which will cause damage to the strip's internal structure.



ASSEMBLY INSTRUCTIONS

8


Use screws ② to mount parts H on F and G.













H x2	
② x4	
⑪ x1	

ASSEMBLY INSTRUCTIONS

9 Use screw ② to assemble L and M into a water cup holder, then use plastic spacers ⑥ and screws ⑤ to install the water cup holder and headphone hook K on table legs. Install part ⑧ on desk board B with screws ④.




K x1		L x1		M x1		2 x1		4 x2	
5 x2		6 x4		8 x1		11 x1		12 x1	

ASSEMBLY INSTRUCTIONS

10

Use screws ④ to fix the light strip controller ⑦ on part A and **keep it on the same side as the light strip output wires.**

After installation, connect the light strip with the light strip controller; Part ⑩ can be fixed on part A to store the strip wire.




④ x2	
⑦ x1	
⑩ x1	
⑫ x1	


ASSEMBLY INSTRUCTIONS

11

Connect the USB port of the light strip controller with the USB port of the power outlet or computer host, and the light strip can be energized. The installation is completed.



OR



ASSEMBLY INSTRUCTIONS




Static Color Button



Dynamic Mode Button



Speed & Brightness
and Power Button



STATIC COLOR BUTTON

Press this button once to switch to the static color mode, and then each pressing can change the color.

DYNAMIC MODE BUTTON

Press this button once to switch to the dynamic mode effect, and then each pressing can change the dynamic mode.

Press this button for more than 2s to switch to the demo mode; In the demo mode, the strip will automatically cycle through various dynamic modes.

SPEED & BRIGHTNESS AND POWER BUTTON

A. In the static mode, press this button to adjust the brightness of the light bar; each press can switch to a brightness level.

B. In the dynamic mode, press this button to adjust the dynamic mode speed; each press can switch to a speed level.

C. Press and hold this button to shut it down when the strip is on. Press this button to turn it on when the strip is off.

The product has a power-off memory function; the strip can restore the color, brightness, and mode in the next power-on.

CUSTOMER SERVICE



30-DAY Return Policy

If you're not completely satisfied with your purchase, simply return the merchandise via our official customer support.

Unused merchandise can be refunded or exchanged within 30 days from the original purchase date.



1-Year Warranty

We guarantee your product is free from defects in product material and workmanship for one (1) year starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new one.

Replacement is free and all shipping costs are covered.



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

PROBLEMS YOU MAY ENCOUNTER

PROBLEM	POSSIBLE CAUSE	SOLUTION
Whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Having issue(s) while reading the instruction or completing the assembly.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Table Surface	Board Surface is broken, scratched or lack of some screw holes.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The screw holes that on the board and the steel frame don't line up.	1. Please tighten the screws on the board by 70%, do not tighten completely. 2. Adjusting board and steel frame until the screw holes are lined up, then tighten all the screws.
	The desk board is uneven or not tight that has gaps after being assembled.	1. Loosen the screws in the uneven or gap positions; adjust until the desktops are flat and tight, and then tighten the screws. 2. If your problem still can't be solved, please feel free to contact us.
Steel Frame	The steel frame is bent, broken, painted, rusted or damaged.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The table is unstable after being assembled.	1. Check if the screws are tightened 2. Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3. If your problem still can't be solved, please feel free to contact us.

We are committed to providing our customers with premium quality products and convenient customer service.



MADE IN CHINA