










RECEPTION DESK



Installation Guide




Spare Parts List

| | | |
|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
| A  x88 | B  x88 | C  x62 |
| D  x15 | E  x16 | F  x8 |
| G  x2 | H  x4 | |

1





NO ELECTRIC SCREW DRIVER








P1

2





NO ELECTRIC SCREW DRIVER






P2

3





NO ELECTRIC SCREW DRIVER





P3

4






P4





5



NO ELECTRIC SCREW DRIVER




6




x2




7



NO ELECTRIC SCREW DRIVER




x2






P7

8





NO ELECTRIC SCREW DRIVER

x2






P8

9




NO ELECTRIC SCREW DRIVER

x2




10



x2

11




18

16



A



12

x2

P11

12



B







C





NO ELECTRIC SCREW DRIVER

x2






P12

13




NO ELECTRIC SCREW DRIVER

x2





P13

14



X2



X2
P14

15

